

Service Manual

Cassette Deck

RS-M260

(Silver Face)
(Black Face)

3-Head Stereo Cassette Deck
with Peak-Hold 2-Color FL Meters
and Soft-Touch Controls



This is the Service Manual for the following areas.

- ☐ For all European areas except United Kingdom.
☐ For United Kingdom.

RS-M24 MECHANISM SERIES

Specifications

Track system:	4-track 2-channel stereo recording and playback	Outputs:	LINE; output level 700 mV, output impedance 3.5 k Ω or less, load impedance 22 k Ω over
Tape speed:	4.8 cm/s		HEADPHONE; output level 125 mV, load impedance 8/125 Ω
Wow and flutter:	0.05% (WRMS), $\pm 0.14\%$ (DIN)	Rec/pb connection:	5P DIN type;
Frequency response:	Metal tape; 20–20,000 Hz		input sensitivity 10 mV, input impedance 2.8 k Ω
	25–20,000 Hz (DIN)		output level 700 mV, output impedance 3.5 k Ω
	25–19,000 Hz ± 3 dB	Bias frequency:	75 kHz
	30–14,000 Hz ± 3 dB (0 VU)	Motor:	Electrical control DC governor motor
CrO ₂ /Fe-Cr tape;	20–20,000 Hz	Heads:	3-head system;
	25–20,000 Hz (DIN)		2-SX (Sendust Extra) heads for record/playback (combination type)
	25–18,000 Hz ± 3 dB		1-sendust/ferrite double-gap head for erasure
Normal tape;	20–18,000 Hz	Power requirement:	AC; 110/125/220/240 V, 50–60 Hz
	25–18,000 Hz (DIN)	Power consumption:	16 W
	25–16,000 Hz ± 3 dB	Dimensions:	43.0 cm(W) \times 11.9 cm(H) \times 28.2 cm(D)
Signal-to-noise ratio:	Dolby [*] NR in; 67 dB (above 5 kHz)	Weight:	5.3 kg
	Dolby NR out; 57 dB (signal level = max. recording level, Fe-Cr/CrO ₂ type tape)		
Fast forward and			
rewind time:	Approx. 90 seconds with C-60 cassette tape		
Inputs:	MIC; sensitivity 0.25 mV, input impedance 10 k Ω		
	applicable microphone impedance 400 Ω –10 k Ω		
	LINE; sensitivity 60 mV, input impedance 42 k Ω		

Specifications are subject to change without notice.

* 'Dolby' and the double-D symbol are trademarks of Dolby Laboratories.

Technics



Matsushita Electric Trading Co., Ltd.

P.O. Box 288, Central Osaka Japan

CONTENTS

ITEM	PAGE
LOCATION OF CONTROLS AND COMPONENTS	1
DISASSEMBLY INSTRUCTIONS	2
MEASUREMENT AND ADJUSTMENT METHODS	3
ELECTRICAL PARTS LOCATION	10
SCHEMATIC DIAGRAM	11
CIRCUIT BOARDS	12
WIRING CONNECTION DIAGRAM	13
MECHANICAL PARTS LOCATION	13
CABINET PARTS LOCATION	15

LOCATION OF CONTROLS AND COMPONENTS



- ① Power switch (power)
- ② Cassette holder
- ③ Tape counter and Reset button (tape counter)
- ④ FL (fluorescent level) meters
- ⑤ Input level controls (input level) (L → R)
- ⑥ Headphones jack (phones)
- ⑦ Eject button (▲ eject)
- ⑧ Record button (○ rec)
- ⑨ Rewind/Review button (◀◀ rew/rev)
- ⑩ Fast forward/Cue button (▶▶ ff/cue)
- ⑪ Play button (▶ play)
- ⑫ Stop button (■ stop)
- ⑬ Pause button (|| pause)

- ⑭ 3 head LED display (3 Head System)
- ⑮ Record-muting button (rec mute)
- ⑯ Monitor switch (monitor)
- ⑰ Dolby noise-reduction switch (Dolby NR)
- ⑱ Input selector (input select)
- ⑲ Tape selector (tape select)
- ⑳ Output level control (output level)
- ㉑ Microphone jacks (L mic R)
- ㉒ Line output jacks (LINE OUT) (R · L)
- ㉓ Line input jacks (LINE IN) (R · L)
- ㉔ Record/Playback connection socket (REC/PB)
- ㉕ Voltage selector (VOLTAGE SELECTOR)

DISASSEMBLY INSTRUCTIONS




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7




Fig. 8

Ref. No.	Procedure	To remove ———	Remove ———	Shown in fig. ———
1	1	Case cover	• 4 screws (A)	1
2	2	Bottom cover	• 3 screws (B)	2
3	1 → 3	Power supply circuit board	• 1 screw (C)	3
4	1 → 2 → 4	Front panel	• Cassette lid (D) • 2 volume knobs (E) • 3 red screws (F) • 1 screw (G)	1 1 3 2
5	1 → 2 → 4 → 5	FL meter and FL meter circuit board	• 2 screws (H)	3
6	1 → 2 → 4 → 6	Main circuit board	• Meter cover (I) • 2 knobs (J) • 2 nuts (K) • 2 screws (L) • 6 screws (M) • 3 cord clamer (N) • 1 binder (O)	4 4 5 5 6 3 3
7	1 → 2 → 4 → 7	Mechanism unit	• Cassette holder (P) • 4 red screws (Q) • 1 cord clamer (R) • 2 binders (S) • 3 pin-socket [E] (T)	5 5 3 3, 7 3
8	1 → 2 → 4 → 7 → 8	Operation button assembly	• 2 screws (U)	8

MEASUREMENT AND ADJUSTMENT METHODS

CIRCUIT BOARD AND ADJUSTMENT PARTS LOCATION

















Fig. 1



NOTES: Set switches and controls in the following positions, unless specified otherwise.

- Make sure heads are clean.
- Make sure capstan and pressure roller are clean.
- Judgeable room temperature: $20 \pm 5^{\circ}\text{C}$ ($68 \pm 9^{\circ}\text{F}$).
- Tape selector: Normal.
- Monitor selector: Tape.
- Input level controls: Maximum.
- Output level control: Maximum.
- Dolby NR selector: Out.
- Input selector: Line.

ITEM	MEASUREMENT & ADJUSTMENT
A Head position adjustment Condition: * Playback and pause mode	<p>(The head adjusting plate is provided to adjust the tape touch of the head in cue or review mode.)</p> <ol style="list-style-type: none"> 1. Press the playback button and pause button. 2. Measure the space between the pinch roller and the capstan. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> Standard value: $0.5 \pm 0.3\text{ mm}$ </div> <ol style="list-style-type: none"> 3. If the measured value is not within the standard value, untighten screw (A), and slide the head adjusting plate in the direction of arrow (B) for adjustment (Fig. 2).  <p style="text-align: center;">Fig. 2</p>
B Head azimuth adjustment Condition: * Playback mode Equipment: * VTVM * Oscilloscope * Test tape (azimuth) ...QZZCFM * Test tape (tape path viewer) ...QZZCRD	<p>Combination head azimuth adjustment</p> <ol style="list-style-type: none"> 1. Test equipment connection is shown in fig. 3. 2. Playback azimuth tape (QZZCFM 8kHz). 3. Adjust record/playback head angle adjustment screw (B) in fig. 4 so that output level at LINE OUT becomes maximum. 4. Measure both channels, and adjust levels for equal output. 5. After adjustment lock head adjustment screw with lacquer.  <p style="text-align: center;">Fig. 3</p>  <p style="text-align: center;">Fig. 4</p>
C Erase head height adjustment Condition: * Playback mode Equipment: * Test tape (tape path viewer) ...QZZCRD	<p>Caution:</p> <ol style="list-style-type: none"> 1. Remove screws (D) and (E) to replace the erase head. (Do not remove nut (C) since it is designed for erase head height. Adjustment to maintain performance.) 2. After erase head replacement, check by playing test tape (QZZCRD) back to see that the tape travels properly. 3. For any tape travel performance problem, follow the procedure below for adjustment. <p>Adjustment</p> <ol style="list-style-type: none"> 1. Adjust nut (C) shown in fig. 5 so that the tape may not get curled or malformed by tape guide of the erase head. 2. After adjustment, lock nut (C) with lacquer.  <p style="text-align: center;">Fig. 5</p>
D Tape speed Condition: * Playback mode Equipment: * Digital electronic counter or frequency counter * Test tape... QZZCWAT	<p>Tape speed accuracy</p> <ol style="list-style-type: none"> 1. Test equipment connection is shown in fig. 6. 2. Playback test tape (QZZCWAT 3,000 Hz), and supply playback signal to frequency counter. 3. Measure this frequency. 4. On the basis of 3,000 Hz, determine value by following formula: $\text{Tape speed accuracy} = \frac{f - 3,000}{3,000} \times 100 (\%) \quad \text{where, } f = \text{measured value}$ <ol style="list-style-type: none"> 5. Take measurement at middle section of tape. <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> Standard value: $\pm 1.5\%$ </div> <p>Adjustment method</p> <ol style="list-style-type: none"> 1. Playback the test tape (middle). 2. Adjust so that frequency becomes 3,000 Hz. 3. Tape speed adjustment VR shown in fig. 1. <p>Note: Please use non metal type screwdriver when you adjust tape speed accuracy on this unit.</p>  <p style="text-align: center;">Fig. 6</p>



ITEM	MEASUREMENT & ADJUSTMENT																																								
	<p>Tape speed fluctuation</p> <p>Make measurements in same manner as above (beginning, middle and end of tape), and determine the difference between maximum and minimum values and calculate as follows:</p> $\text{Tape speed fluctuation} = \frac{f_1 - f_2}{3,000} \times 100 (\%) \quad f_1 = \text{maximum value, } f_2 = \text{minimum value}$ <div style="border: 1px solid black; padding: 5px; text-align: center;">Standard value: Less than 1%</div>																																								
<p>⑤ Playback frequency response</p> <p>Condition:</p> <ul style="list-style-type: none">• Playback mode• Normal position• Output level control...MAX <p>Equipment:</p> <ul style="list-style-type: none">• VTVM• Oscilloscope• Test tape...QZZCFM	<p>Measurement</p> <ol style="list-style-type: none">1. Test equipment connection is shown in fig. 3.2. Place UNIT into playback mode.3. Playback the frequency response test tape (QZZCFM).4. Measure output level at 315 Hz, 12.5 kHz, 8 kHz, 4 kHz, 1 kHz, 250 Hz, 125 Hz and 63 Hz and compare each output level with the standard frequency 315 Hz, at LINE OUT.5. Make measurement for both channels.6. Make sure that the measured value is within the range specified in the frequency response chart (Fig. 7). <p>Adjustment method</p> <ol style="list-style-type: none">1. If the measured value is not within the standard at the high frequency range, P.C.B. connection points (a) (L-CH) and (a') (R-CH) should be short-circuited (Fig. 12). In this case, connection points (b) (L-CH) and (b') (R-CH) should be opened.2. Make measurement again according to steps from (2) to (6) of the "Measurement" above.3. If the measured value decreases at high frequency range, as shown in fig. 8, P.C.B. connection points (b) (L-CH) and (b') (R-CH) should be shorted (Fig. 12). <div><p>Compensation value</p><table><tr><td>4 kHz</td><td>6 kHz</td><td>8 kHz</td><td>10 kHz</td><td>12.5 kHz</td></tr><tr><td>around +0.3 dB</td><td>around +0.5 dB</td><td>around +0.7 dB</td><td>around +0.7 dB</td><td>around +0.6 dB</td></tr></table></div> <div><p style="text-align: center;">Fig. 8</p></div> <ol style="list-style-type: none">4. If the measured value increases at the high frequency range, as shown in fig. 9, P.C.B. connection points (a) (L-CH) and (a') (R-CH) should be opened. Connection points (b) (L-CH) and (b') (R-CH) should be short-circuited. <div><p>Compensation value</p><table><tr><td>4 kHz</td><td>6 kHz</td><td>8 kHz</td><td>10 kHz</td><td>12.5 kHz</td></tr><tr><td>around -0 dB</td><td>around -0.3 dB</td><td>around -0.4 dB</td><td>around -0.5 dB</td><td>around -0.7 dB</td></tr></table></div> <div><p style="text-align: center;">Fig. 9</p></div> <ol style="list-style-type: none">5. If the measured value decreases at middle frequency range, as shown in fig. 10, P.C.B. connection points (c) (L-CH) and (c') (R-CH) should be opened (Fig. 12). <div><p>Compensation value</p><table><tr><td>700 Hz</td><td>1 kHz</td><td>2 kHz</td><td>4 kHz</td><td>10 kHz</td></tr><tr><td>around +0.2 dB</td><td>around +0.4 dB</td><td>around +0.7 dB</td><td>around +0.7 dB</td><td>around +0.9 dB</td></tr></table></div> <div><p style="text-align: center;">Fig. 10</p></div> <ol style="list-style-type: none">6. If the measured value increases at middle frequency range, as shown in fig. 11, P.C.B. connection points (c) (L-CH) and (c') (R-CH) should be shorted (Fig. 12). <div><p>Compensation value</p><table><tr><td>700 Hz</td><td>1 kHz</td><td>2 kHz</td><td>4 kHz</td><td>10 kHz</td></tr><tr><td>around -0.2 dB</td><td>around -0.4 dB</td><td>around -0.7 dB</td><td>around -0.9 dB</td><td>around -0.9 dB</td></tr></table></div> <div><p style="text-align: center;">Fig. 11</p></div>	4 kHz	6 kHz	8 kHz	10 kHz	12.5 kHz	around +0.3 dB	around +0.5 dB	around +0.7 dB	around +0.7 dB	around +0.6 dB	4 kHz	6 kHz	8 kHz	10 kHz	12.5 kHz	around -0 dB	around -0.3 dB	around -0.4 dB	around -0.5 dB	around -0.7 dB	700 Hz	1 kHz	2 kHz	4 kHz	10 kHz	around +0.2 dB	around +0.4 dB	around +0.7 dB	around +0.7 dB	around +0.9 dB	700 Hz	1 kHz	2 kHz	4 kHz	10 kHz	around -0.2 dB	around -0.4 dB	around -0.7 dB	around -0.9 dB	around -0.9 dB
4 kHz	6 kHz	8 kHz	10 kHz	12.5 kHz																																					
around +0.3 dB	around +0.5 dB	around +0.7 dB	around +0.7 dB	around +0.6 dB																																					
4 kHz	6 kHz	8 kHz	10 kHz	12.5 kHz																																					
around -0 dB	around -0.3 dB	around -0.4 dB	around -0.5 dB	around -0.7 dB																																					
700 Hz	1 kHz	2 kHz	4 kHz	10 kHz																																					
around +0.2 dB	around +0.4 dB	around +0.7 dB	around +0.7 dB	around +0.9 dB																																					
700 Hz	1 kHz	2 kHz	4 kHz	10 kHz																																					
around -0.2 dB	around -0.4 dB	around -0.7 dB	around -0.9 dB	around -0.9 dB																																					








ITEM	MEASUREMENT & ADJUSTMENT
	 <p>Connection points for playback equalization adjustment (L-CH)</p> <p>Connection point (a)</p> <p>Connection point (b)</p> <p>Connection point (c)</p> <p>Connection point (a')</p> <p>Connection point (b')</p> <p>Connection point (c')</p> <p>Connection points for playback equalization adjustment (R-CH)</p> <p>MAIN CIRCUIT BOARD</p>
<p>Ⓕ Playback gain</p> <p>Condition:</p> <ul style="list-style-type: none"> * Playback mode * Normal position * Output level control ... MAX <p>Equipment:</p> <ul style="list-style-type: none"> * VTVM * Oscilloscope * Test tape ... QZZCFM 	<p>1. Test equipment connection is shown in fig. 3.</p> <p>2. Playback standard recording level portion on test tape (QZZCFM 315Hz), and using VTVM measure the output level at LINE OUT.</p> <p>3. Make measurement for both channels.</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> Standard value: around 0.7 V </div> <p>Adjustment</p> <p>1. If measured value is not standard, adjust VR1 (L-CH), VR2 (R-CH) (See fig. 1).</p> <p>2. After adjustment, check "Ⓕ Playback frequency response" again.</p>
<p>Ⓖ Bias leakage</p> <p>Condition:</p> <ul style="list-style-type: none"> * Record mode * Input level controls ... MAX * Output level control ... MAX * Tape selector ... Metal position <p>Equipment:</p> <ul style="list-style-type: none"> * VTVM * Oscilloscope 	<p>Adjustment (For record amp)</p> <p>1. Test equipment connection is shown in fig. 13.</p> <p>2. Place UNIT into record mode.</p> <p>3. Adjust trap coils L205 (L-CH), L206 (R-CH), so that measured value becomes minimum.</p> <p>Adjustment (For playback amp)</p> <p>1. Test equipment connection is shown in fig. 14.</p> <p>2. Turn the UNIT into record mode and set the monitor selector to tape position.</p> <p>3. Adjust trap coils L1 (L-CH) and L2 (R-CH), so that measured values are minimized at LINE OUT.</p> <div style="text-align: right;">  <p>Fig. 13</p>  <p>Fig. 14</p> </div>
<p>Ⓗ Erase current</p> <p>Condition:</p> <ul style="list-style-type: none"> * Record mode * Tape selector ... Metal position <p>Equipment:</p> <ul style="list-style-type: none"> * VTVM * Oscilloscope 	<p>1. Test equipment connection is shown in fig. 15.</p> <p>2. Place UNIT into record mode and measure voltage at test point 9.</p> <p>3. Determine erase current with the following formula:</p> $\text{Erase current (A)} = \frac{\text{Voltage across both ends of R403}}{1 (\Omega)}$ <div style="border: 1px solid black; padding: 5px; text-align: center;"> Standard value: $100 \pm 20_5$ mA (Tape selector ... Metal) </div> <p>4. If measured value is not within standard, adjust VR403.</p> <div style="text-align: right;">  <p>Fig. 15</p> </div>

ITEM	MEASUREMENT & ADJUSTMENT	
<div>❶ Bias current</div> <div>Condition:<ul style="list-style-type: none">* Record mode* Tape selector<ul style="list-style-type: none">... Normal position... Fe-Cr position... CrO₂ position... Metal position</div> <div>Equipment:<ul style="list-style-type: none">* VTVM* Oscilloscope</div>	<div><div><div>1. Test equipment connection is shown in fig. 16.</div><div>2. Place UNIT into record mode, and tape selector to normal position.</div><div>3. Read voltage on VTVM and calculate bias current by following formula:<div>$\text{Bias current (A)} = \frac{\text{Value read on VTVM (V)}}{10 (\Omega)}$</div></div></div></div> <div><div>Standard value: 0.7±0.3 mA (Normal position)</div></div> <div><div>4. Adjust VR402 (L-CH) and VR401 (R-CH).</div><div>5. Set the tape selector to each position.</div><div>6. Make sure that the measured value is within standard.</div></div> <div><div>Standard value: 0.75±0.3 mA (Fe-Cr position)</div><div>1.0±0.3 mA (CrO₂ position)</div><div>1.6±0.3 mA (Metal position)</div></div>	<div></div> <div>Fig. 16</div>
<div>❷ Overall gain</div> <div>Condition:<ul style="list-style-type: none">* Record/playback mode* Tape selector<ul style="list-style-type: none">... Normal position... Fe-Cr position... CrO₂ position... Metal position* Input level controls... MAX* Output level control... MAX* Standard input level:<ul style="list-style-type: none">MIC..... - 72±3 dBLINE IN... - 24±3 dB</div> <div>Equipment:<ul style="list-style-type: none">* VTVM* AF oscillator* ATT* Oscilloscope* Test tape (reference blank tape)<ul style="list-style-type: none">... QZZCRA for Normal... QZZCRX for Fe-Cr... QZZCRY for CrO₂... QZZCRZ for Metal</div>	<div><div><div>1. Test equipment connection is shown in fig. 17.</div><div>2. Place the test tape (QZZCRA) in the cassette holder.</div><div>3. Place UNIT into record mode, and tape selector to normal position.</div><div>4. Supply 1kHz signal (-24 dB) from AF oscillator, through ATT to LINE IN.</div><div>5. Adjust ATT until monitor level at LINE OUT becomes 0.7 V.</div><div>6. Using test tape, make recording.</div><div>7. Playback recorded tape, and measure the output level at LINE OUT on VTVM.</div></div></div> <div><div>Standard value: 0.7V±1.5 dB (Normal position)</div></div> <div><div>8. If measured value is not within standard, adjust VR203 (L-CH), VR204 (R-CH).</div><div>9. Repeat from step (4).</div><div>10. Change the tape selector to each position.</div><div>11. Change test tape to Fe-Cr (QZZCRY), CrO₂ (QZZCRX) and Metal (QZZCRZ).</div><div>12. Place UNIT into record mode.</div><div>13. Playback recorded tape, and measure the output level at LINE OUT on VTVM.</div></div> <div><div>Standard value: 0.7V±1.5 dB (Fe-Cr, CrO₂ and Metal position)</div></div> <div><div>14. If measured value is not within standard, adjust as follows.</div><div>15. Adjust overall gain by short-circuiting or opening the point on the printed pattern in fig. 18, so that each positions approach their standard values.</div><div>16. Refer to the following tables for overall gain adjustment.</div></div>	<div></div> <div>Fig. 17</div>

Fe-Cr position (L-CH)			CrO ₂ position (L-CH)			Metal position (L-CH)		
Gain	Point (d)	Point (e)	Gain	Point (f)	Point (g)	Gain	Point (h)	Point (i)
LOW	CLOSE	CLOSE	LOW	CLOSE	CLOSE	LOW	CLOSE	CLOSE
↕	CLOSE	OPEN	↕	CLOSE	OPEN	↕	CLOSE	OPEN
	OPEN	CLOSE		OPEN	CLOSE		OPEN	CLOSE
HIGH	OPEN	OPEN	HIGH	OPEN	OPEN	HIGH	OPEN	OPEN

Fe-Cr position (R-CH)			CrO ₂ position (R-CH)			Metal position (R-CH)		
Gain	Point (d')	Point (e')	Gain	Point (f')	Point (g')	Gain	Point (h')	Point (i')
LOW	CLOSE	CLOSE	LOW	CLOSE	CLOSE	LOW	CLOSE	CLOSE
↕	CLOSE	OPEN	↕	CLOSE	OPEN	↕	CLOSE	OPEN
	OPEN	CLOSE		OPEN	CLOSE		OPEN	CLOSE
HIGH	OPEN	OPEN	HIGH	OPEN	OPEN	HIGH	OPEN	OPEN


Fig. 16

Fig. 17




ITEM	MEASUREMENT & ADJUSTMENT
	 <p style="text-align: center;">Fig. 18</p>
<p>⊗ Overall frequency response</p> <p>Condition:</p> <ul style="list-style-type: none"> * Record/playback mode * Tape selector <ul style="list-style-type: none"> ... Normal position ... Fe-Cr position ... CrO₂ position ... Metal position * Input level controls... MAX * Output level control <ul style="list-style-type: none"> ... MAX <p>Equipment:</p> <ul style="list-style-type: none"> * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω) * Test tape (reference blank tape) <ul style="list-style-type: none"> ... QZZCRA for Normal ... QZZCRY for Fe-Cr ... QZZCRX for CrO₂ ... QZZCRZ for Metal 	<p>Note 1: Before measuring and adjusting, make sure of the playback frequency response (For the method of measurement, please refer to the playback frequency response).</p> <p>Note 2: Test tape QZZCRA to be supplied after July 1980 has higher recording sensitivity in the middle and high frequency range.</p> <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <ul style="list-style-type: none"> *  This chart indicates the standard values for the new type of QZZCRA when in use. *  This chart indicates the standard values for the former type of QZZCRA when in use. <p>The new type of QZZCRA is marked as shown in fig. 20.</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: center;"> <p>Former type</p>  </div> <div style="margin: 0 20px;">➔</div> <div style="text-align: center;"> <p>New type</p>  <p>Marking</p> </div> </div> <p style="text-align: center;">Fig. 20</p> </div> <div style="flex: 1;"> <p style="text-align: center;">Overall frequency response chart (Normal)</p>  <p style="text-align: center;">Fig. 19</p> </div> </div> <p>Measurement</p> <ol style="list-style-type: none"> Test equipment connection is shown in fig. 17. Place the normal test tape (QZZCRA) in the cassette holder. Place UNIT into record mode, and tape selector to normal position. Supply 1kHz signal from AF oscillator through ATT to LINE IN. Adjust ATT so that input level is -20 dB below standard recording level (standard recording level = 0 VU). At this time, LINE OUT level indicates 0.07 V. Record each frequency 1kHz, 50Hz, 200Hz, 4kHz, 8kHz and 13kHz (15kHz for Fe-Cr, CrO₂ and metal). Playback and express in dB the difference between playback output level of each frequency based on playback output level of 1kHz. Make sure that the measured value is within the range specified in the overall frequency response chart (Shown in fig. 19). Change test tape to Fe-Cr (QZZCRY), CrO₂ (QZZCRX) and metal (QZZCRZ). <div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p style="text-align: center;">Overall frequency response chart (Fe-Cr, CrO₂ and Metal)</p>  <p style="text-align: center;">Fig. 21</p> </div> </div>

ITEM	MEASUREMENT & ADJUSTMENT
	<p>11. Set the tape selector to each position. 12. Measure in the same manner from step (3) to (8). 13. Make sure that the measured value is within the range specified in the overall frequency response chart for Fe-Cr, CrO₂ and metal tape (Shown in fig. 21).</p> <p>Adjustment-1: Using bias current</p> <p>1. When the frequency response between the middle and high frequency range becomes higher than the standard value, as shown by the solid line in fig. 22, increases the bias current by turning VR402 (L-CH), VR401 (R-CH). 2. When it becomes lower, as shown by dotted line, reduce the bias current by turning VR402 (L-CH), VR401 (R-CH).</p> <p>Note: For the method of bias current measurement, refer to "① Bias current adjustment" on page 7.</p> <p>Adjustment-2: Using the peaking coil for recording equalization</p> <p>When the frequency response is flat in the middle frequency range and makes a sharp rise or drop in the high frequency range, as shown in fig. 23, adjust by turning the following peaking coils. L203 (L-CH), L204 (R-CH).</p> <div data-bbox="1152 474 1434 672"> <p>Fig. 22</p> </div> <div data-bbox="1152 712 1434 929"> <p>Fig. 23</p> </div>
<p>② Fluorescent meter</p> <p>Condition:</p> <ul style="list-style-type: none"> * Record mode * Input level controls... MAX * Output level control... MAX * Tape selector ... Normal position <p>Equipment:</p> <ul style="list-style-type: none"> * VTVM * AF oscillator * ATT 	<p>1. Test equipment connection is shown in fig. 17. 2. As shown in fig. 24, connecting the base of Q102 and ground stops the oscillation of the stable multivibrator comprising Q102 and Q103. 3. Supply 1kHz signal (−24 dB) to the LINE IN jack, then press the record button. 4. Adjust the ATT so that the output level at LINE OUT jack becomes 0.7 V (The input level at this condition is termed the standard input level). 5. Adjustment at "−20 dB": A. Adjust the ATT so that input level is −20 dB below standard recording level. B. Adjust VR101 so that the −20 dB segment lights up in the -20 ± 0.8 dB range (L-CH ONLY) (See fig. 25). 6. Adjustment at "0 dB": A. Adjust the ATT so that the output level at LINE OUT jack becomes 0.7 V. (The input level at this condition is termed the standard input level.) B. Adjust VR102 so that the +1 dB segment lights up in the 0 ± 0.2 dB range of the standard input level (See fig. 26). 7. Repeat twice between steps (5) and (6) above. 8. Adjust ATT and check that all segments light up when an input signal level is increased to 10 dB higher than the standard input level (See fig. 27).</p> <div data-bbox="1066 985 1481 1243"> <p>Fig. 24</p> </div> <div data-bbox="1066 1265 1481 1400"> <p>Fig. 25</p> </div> <div data-bbox="1066 1422 1481 1556"> <p>Fig. 26</p> </div> <div data-bbox="1066 1579 1481 1713"> <p>Fig. 27</p> </div>
<p>③ Dolby NR circuit</p> <p>Condition:</p> <ul style="list-style-type: none"> * Record mode * Input level controls... MAX * Output level control... MAX <p>Equipment:</p> <ul style="list-style-type: none"> * VTVM * AF oscillator * ATT * Oscilloscope * Resistor (600Ω) 	<p>1. Test equipment connection is shown in fig. 28. 2. Place UNIT into record mode, set the Dolby NR switch to OUT position and supply to LINE IN to obtain −34.5 dB at TP5 (L-CH), TP6 (R-CH) (frequency 5 kHz). 3. Confirm that the value at IN position is $8 (\pm 2.5)$ dB greater than the value at OUT position of Dolby NR switch.</p> <div data-bbox="1066 1736 1481 1982"> <p>Fig. 28</p> </div>


ELECTRICAL PARTS LOCATION

NOTE: Δ indicates that only parts specified by the manufacturer be used for safety.

Ref. No.	Part No.	Part Name & Description
ELECTRICAL PARTS		
E1	QWY4125Z	Record/Playback Head (Combination Type)
E2	QWY2133Z	Erase Head
E3	QTSM0035	Earth Plate (A)
E4	QTD1001	Lug Terminal
E5	XTB3+10BFZ	Tapping Screw $\Phi 3 \times 10$
E6	QJT4017	4 Pin Terminal
E7	QTHM0010	Heat Sink (A)
E8	QTSM0021	Shield Plate
E9	QJP1921TN	3 Pin Post
E10	QJP1922TN	6 Pin Post
E11	QJT1054	Contact
E12	XSN3+8S	Screw $\Phi 3 \times 8$
E13	XWA3B	Washer 3 ϕ
E14	XNG3ES	Nut 3 ϕ
E15	XWG3	Washer 3 ϕ
E16	QSLM006RF	FL Meter
E17	QTSM0040	Shield Plate
E18	QBMM0019	Meter Cushion
E19	QTHM0009	Heat Sink (B)
E20	Δ QTF1054	Fuse Holder
E21	QJT1067	1 Pin Terminal
E22	Δ SJA88	AC Power Cord
*For all European areas except United Kingdom.		
Δ QFC1205M		
*For United Kingdom.		
E23	QTD1164	Cord Clamper
E24	QB1425	Cord Bushing
E25	QTSM0043	Earth Terminal (1)
E26	QTSM0042	Earth Terminal (2)
E27	XTN3+16B	Tapping Screw $\Phi 3 \times 16$
E28	XTB4+10BFZ	Tapping Screw $\Phi 4 \times 10$
E29	XTN3+10B	Tapping Screw $\Phi 3 \times 10$
E30	XWG3	Washer 3 ϕ
E31	XSN3+8S	Screw $\Phi 3 \times 8$
E32	XWA3B	Washer
E33	XTB3+10BFZ	Tapping Screw $\Phi 3 \times 10$
E34	XSN3+6S	Screw $\Phi 3 \times 6$
E35	XTB3+8BFZ	Tapping Screw $\Phi 3 \times 8$
E36	XWG3	Washer
E37	QNQ1070	Nut
E38	XNS8	Nut 8 ϕ
E39	XNS9	Nut 9 ϕ
E40	QJS1921TN	3 Pin Socket
E41	QJS1922TN	6 Pin Socket





SCHEMATIC DIAGRAM




MAIN CIRCUIT BOARD


IC6 AN6870

**IC305 AN6552**

TERMINATIONS (SIDE VIEW)



Q1-18
Q101-103
Q201-210
Q401-411



0501.502

NOTES:

- S1-1—S1-3 Dolby in/out select switch (shown in out position).
 - S2-1, S2-2 Monitor select switch (shown in tape position).
 - S3-1, S3-2 Input select switch (shown in line position).
 - S4-1—S4-4 Tape select switch (shown in normal position).
 - S5 Record mute switch (shown in off position).
 - S6 Record switch (shown in off position).
 - S7 Muting switch (shown in off position).
 - S8 Pause switch (shown in off position).
 - S9 Cue/review muting switch (shown in off position).
 - S10 Power on/off switch.
 - S11 AC power voltage select switch.
 - VR1, 2 Playback gain adjustment VR.
 - VR3, 4 Output level control.
 - VR101 FL meter adjustment VR (for -20dB indication).
 - VR102 FL meter adjustment VR (for 0dB indication).
 - VR201, 202 Input level control.
 - VR203, 204 Overall gain adjustment VR.
 - VR401, 402 Bias current adjustment VR.
 - VR403 Erase current adjustment VR (for metal position).
 - L1, 2 Bias leakage adjustment coil (for playback amp).
 - L203, 204 Recording equalization adjustment coil.
 - L205, 206 Bias leakage adjustment coil (for record amp).
 - Connection points (a), (a'), (b), (b'), (c) and (c')
 Connection points for playback equalization adjustment.
 - Connection points (d), (d'), (e), (e'), (f), (f'), (g), (g'), (h), (h'), (i) and (i')
 Connection points for overall gain adjustment.
 - Resistance are in ohms (Ω), 1/4 watt unless specified otherwise.
 K = 1,000 Ω , M = 1,000 k Ω .
 - Capacity are in microfarads (μ F) unless specified otherwise.
 P = Pico-farads.
 - The mark (▼) shows test point. e.g. ▼ = Test point 1.
 - All voltage values shown in circuitry are under no signal condition and record mode with volume control at minimum position.
- For measurement, use VTMV.
- (⇨) this arrow indicates the flow of the playback signal.
 - (⇨) this arrow indicates the flow of the recording signal.
 - (⇨) this arrow indicates the flow of the playback and recording signal in combination.

SPECIFICATIONS

Playback S/N ratio Test tape... QZZCFM	More than 47 dB (without NAB filter)
Overall distortion Test tape ... QZZCRA for Normal ... QZZCRX for CrO ₂ ... QZZCRY for Fe-Cr ... QZZCRZ for Metal	Less than 2.3% (Normal) Less than 3.3% (Fe-Cr, CrO ₂ and Metal)
Overall S/N ratio Test tape... QZZCRX	More than 45 dB (without NAB filter)

NOTES: RESISTORS

ERD ... Carbon
ERG ... Metal-oxide
ERS ... Metal-oxide
ERO ... Metal-film
ERX ... Metal-film
ERQ ... Fuse type metallic
ERC ... Solid
ERF ... Cement

CAPACITORS

ECG□ Ceramic
ECK□ Ceramic
ECC□ Ceramic
ECF□ Ceramic
EQQM Polyester film
ECQE Polyester film
ECQF Polypropylene
ECF□ Electrolytic


ECE□N ... Non polar electrolytic

ECQS..... Polystyrene
ECS□ Tantalum
QCS Tantalum

NOTE: Δ indicates that only parts specified by the manufacturer be used for safety.

Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.
RESISTORS									
R1. 2	ERD25FJ101	R124	ERQ14AJ151	R406	ERD25FJ100	C205, 206	ECEA1CS330	Q13, 14, 15, 16	2SC945
R3, 4	ERD25FJ560	R125	ERD25FJ103	R407, 408	ERD25FJ390	C207, 208	ECCD1H470K	Q17, 18	2SA999E
R5, 6	ERD25CKF1003	R126	ERD25FJ332	R409, 410	ERD25FJ472	C209, 210, 211, 212		Q101, 102, 103	
R7, 8	ERD25FJ472	R127, 128	ERD25TJ684	R411	ERD25FJ683		ECEA1HS100		2SC945
R9, 10	ERD25CKF1003	R129	ERD25FJ102	R412	ERD25FJ392	C213	ECEA1ES470	Q201, 202, 203, 204	2SC1327
R11, 12	ERD25FJ472	R201, 202	ERD25FJ392	R413	ERD25FJ272	C214	ECEA1CS331	Q205, 206	2SD592NCS
R13, 14	ERD25FJ821	R203, 204	ERD25FJ101	R414	ERD25TJ104	C215, 216	ECEA1AS221	Q207, 208, 209, 210	2SC945
R17, 18	ERD25TJ124	R205, 206	ERD25FJ273	R415	ERD25TJ474	C221, 222	ECEA0MR33R		
R19, 20	ERD25TJ393	R207, 208	ERD25CKF1003	R416	ERD25TJ393	C223, 224, 225, 226	EQCM1H273JZ		
R21, 22	ERD25FJ472	R211, 212	ERD25FJ820	R417	ERD25TJ683		ECEA1HS100	Q401, 402	2SC592NCS
		R213, 214	ERD25CKF1003	R419, 420	ERD25FJ273	C227, 228	EQCM1H472JZ	Q403	2SD946
R23, 24	ERD25FJ562	R215, 216	ERD25FJ472	R421	ERQ14AJ101P	C229, 230	EQCM1H562JZ	Q404, 405, 406, 407, 408	2SC945
R25, 26	ERD25TJ104	R217, 218	ERD25FJ821	R422	ERD25FJ562	C233, 234	EQCM1H473KZ	Q409, 410, 411	2SA999E
R27, 28, 29, 30				R424	ERD25FJ100			Q501, 502	2SD794P
		R221, 222, 223, 224		R425	ERD25TJ473	C235, 236, 237, 238		INTEGRATED CIRCUITS	
R31, 32	ERD25FJ272		ERD25FJ102	R426, 427	ERD25FJ102		ECEA1HS100		
R33	ERG1ANJ151	R225, 226	ERD25TJ394	R428	ERD25FJ561	C239, 240	EQCV05104JZ		
R34	ERD25FJ682	R227, 228	ERD25FJ332			C241, 242	ECEA50ZR33		
R35, 36	ERD25FJ102	R229, 230	ERD25FJ181	R429	ERD25TJ823	C243, 244	ECKD1H151KB	IC1, 2, 3, 4 NE646B	
R37, 38	ERD25FJ332	R235, 236	ERD25TJ473	R430	ERD25FJ681	C245, 246	ECEA50ZR47		
R39, 40	ERD25TJ684	R237, 238	ERD25TJ684	R431	ERD25FJ222	C247, 248	EQCM1H681KB	IC5 AN6552	
R41, 42	ERD25TJ473	R239, 240	ERD25TG2003	R432, 433	ERD25FJ103	C249, 250	ECEA1CS330	IC6 AN6870	
		R241, 242	ERD25TJ274	R434	ERD25FJ562	C251, 252	ECEA1HS100		
R43, 44	ERD25FJ181	R243, 244	ERD25TJ683	R435	ERG1ANJ121			COMBINATION PARTS	
R47, 48	ERD25TG2003	R247, 248	ERD25FJ472	R436	ERD25TJ223	C253, 254	ECEA50ZR33		
R49, 50				R501	ERQ14AJ100P	C255, 256	ECKD1H151KB	CR1, 2 EXRP681K472	
R51	ERD25TJ683	R249, 250	ERD25TJ123	R502, 504	ERD25FJ681	C257, 258	EQCM1H183JZ	CR3, 4 EXRP122K472	
R52	ERD25FJ391	R251, 252, 253, 254		R503, 504	ERQ14AJ181P	C259, 260	EQCM1H822KZ	CR201, 202 EXRP681K472	
R53, 54	ERD25FJ152		ERD25FJ103			C263, 264	EQCM1H333JZ	CR203, 204, 205, 206	
R55, 56	ERD25FJ472	R255, 256	ERD25TJ393			C265, 266	EQCM1H273KZ	EXRP122K473	
R57, 58	ERD25TJ154	R257, 258	ERD25TJ823	R601	ERD25FJ472	C267, 268	EQCM1H683KZ	EXRP222K222	
R59, 60	ERD25TJ333	R259, 260	ERD25TJ183	R602	ERD50FJ152	C269, 270	EQCM1H273KZ		
R61, 62	ERD25FJ182	R261, 262	ERD25TJ563	R603	ERG12ANJ182	C271, 272	EQCM1H393KZ		
		R263, 264	ERD25TJ104			C273, 274	EQCM1H273KZ		
		R265, 266, 267, 268		VARIABLE RESISTORS					
R63, 64	ERD25FJ561		ERD25TJ563	VR1, 2	EVNKA4A00B24	C275, 276	EQCM1H473KZ		
R65, 66	ERD25FJ181		ERD25TJ124	VR3, 4	QWKGTA02AA1B	C277	ECEA1ES471	TR	
R67, 68	ERD25FJ152	R269, 270	ERD25TJ104	VR101	EVNKA4A00B52	C279, 280	ECKD1H152KB	T501 Δ QLPD51EM	
R69	ERD25FJ332	R271, 272		VR102	EVNKA4A00B14	C281, 282	ECEA1JS4R7		
R71, 72	ERD25TJ104			VR201, 202	QVKDM80RA24	C283, 284	EQCP1471JZ	L1, 2 QLQX1032W	
R73, 74	ERD25FJ392	R273, 274	ERD25FJ222	VR203, 204	EVNKA4A00B54	C401, 402	ECKD1H151KB		
R75, 76	ERD25FJ102	R275, 276	ERD25TJ103	VR401, 402	EVNKA4A00B54	C403	EQCF433KZH	L201, 202 QLM9Z6K	
R77, 78	ERD25TJ104	R277, 278	ERD25TJ393	VR403	EVNKA4A00B24	C404, 405	ECEA1HS100	L203, 204 QLCQ2721K	
R79, 80	ERD25TJ473	R279, 280	ERD25FJ332			C406, 407	EQCM1H822KZ	L205, 206 QLQX1032W	
R81, 82, 83, 84		R281, 282	ERD25FJ330			C408	EQCM1H472KZ		
	ERD25FJ102	R283, 284, 285, 286		CAPACITORS					
R85, 86, 87, 88			ERD25FJ470	C1, 2	ECKD1H471KB	C409	ECEA2AS2R2	C409 ECEA2AS2R2	
	ERD25FJ220	R287, 288	ERD25FJ680	C3, 4	ECKD1H221KB	C410	ECEA1HS100	C410 ECEA1HS100	
R89, 90	ERD25FJ102	R289, 290	ERD25FJ821	C5, 6	ECEA16M10R	C412, 413	ECEA1HS470	C412, 413 ECEA1HS470	
R91, 92	ERD25FJ330	R291, 292	ERD25FJ182	C7, 8	ECEA1ES330	C414	ECEA1HS100	C414 ECEA1HS100	
R93	ERD25TJ683	R293, 294	ERD25FJ102	C9, 10	ECKD1H102KB	C415	ECEA1JS4R7	C415 ECEA1JS4R7	
R101, 102	ERD25TJ223			C13, 14	ECEA1CS330	C416	ECEA1VS221	C416 ECEA1VS221	
R103, 104	ERD25TJ104	R301	ERD25FJ331	C15, 16	ECEA1CS330	C417	ECEA2AS3R2	C417 ECEA2AS3R2	
R105, 106	ERD25TG2702	R303, 304	ERD25FJ152	C17, 18	ECEA1HS100	C418	EQCM1H183KZ	C418 EQCM1H183KZ	
R107	ERD25TJ153	R305, 306	ERD25FJ472	C19, 20	EQCM1H123JZ	C501	ECEA1VS102	C501 ECEA1VS102	
R108	ERD25FJ180	R307, 308	ERD25FJ151	C21, 22	ECEA1ES470	C502	ECKD1H103P	C502 ECKD1H103P	
R109	ERD25FJ561	R309, 310	ERD25TJ224						
		R311, 312	ERD25FJ103	C23	ECEA1CS331	C503 Δ	ECEA1ES221	C503 Δ ECEA1ES221	
R111, 112, 113, 114		R313	ERD25FJ152	C24	ECEA1HS100	C504 Δ	ECEA1ES331	C504 Δ ECEA1ES331	
	ERD25TJ223	R315, 316	ERG1ANJ151	C25, 26	ECEA1AS221	C505 Δ	ECKD1H103P	C505 Δ ECKD1H103P	
R115, 116	ERD25TG1003	R401, 402	ERD25FJ100	C27, 28	ECEA50MR33R	C506 Δ	ECEA1VS102	C506 Δ ECEA1VS102	
R117, 118	ERD25FJ331			C29, 30	EQCP1471JZ	C507 Δ	ECEA1ES222	C507 Δ ECEA1ES222	
R119, 120	ERD25TJ224			C31, 32	EQCM1H273JZ	C508	ECKD1H103P	C508 ECKD1H103P	
R121, 122	ERD25FJ102	R403	ERD25FJ1R0	C33, 34	ECKD1H152KB	DIODES & RECTIFIERS			
R123	ERD25FJ822	R404, 405	ERD25TJ683	C35, 36	ECEA1HS100	D1, 2	MA161	D1, 2 MA161	
				C37, 37	EQCM1H472JZ	D101, 102	MA161	D101, 102 MA161	
				C39, 40	ECEA1HS100	D103	WV121	D103 WV121	
						D104	MA161	D104 MA161	
				C41, 42	EQCM1H562JZ	D201, 202	MA161	D201, 202 MA161	
				C45, 46	EQCM1H473KZ	D401, 402, 403, 404, 405, 406, 407, 408	MA161	D401, 402, 403, 404, 405, 406, 407, 408 MA161	
				C47, 48	ECEA1HS100	D409	RD22EB1	D409 RD22EB1	
				C49, 50	EQCV05104JZ	D501 Δ	RD22EB1	D501 Δ RD22EB1	
				C51, 52	ECEA50ZR33	D502, 503, 504, 505		D502, 503, 504, 505	
				C53, 54	ECEA2AS3R3	Δ	SM112	Δ SM112	
				C55	ECEA1ES221	D601	LD001UR	D601 LD001UR	
				C57, 58	ECEA2AS3R3	D602	LD001GG	D602 LD001GG	
				C59, 60	ECEA2AS010	D603	LD001YY	D603 LD001YY	
				C61, 62	ECEA1HS100	TRANSISTORS			
						Q1, 2	2SC1844E	Q1, 2 2SC1844E	
				C63, 64	ECEA1CS221	Q3, 4	2SC1327	Q3, 4 2SC1327	
				C65	ECEA1ES101	Q5, 6, 7, 8, 9, 10	2SC345	Q5, 6, 7, 8, 9, 10 2SC345	
				C101, 102	ECEA50ZR22	Q11, 12	2SD592NCS	Q11, 12 2SD592NCS	
				C103, 104	ECEA2AS3R3				
				C105	EQCM1H473KZ				
				C106	EQCV05104JZ				
				C107	ECEA1JS4R7				
				C108	ECEA1HS100				
				C201, 202	ECEA16M10R				
				C203, 204	ECKD1H102KB				
						</			

FL METER CIRCUIT BOARD



**POWER
CIRCUIT**

ATORS

- ... Carbon
- ... Metal-oxide
- ... Metal-oxide
- ... Metal-film
- ... Metal-film
- ... Fuse type metallic
- ... Solid
- ... Cement

CAPACITORS

ECG□	Ceramic
ECK□	Ceramic
ECC□	Ceramic
ECF□	Ceramic
ECOM	Polyester film
ECQE	Polyester film
ECQF	Polypropylene
ECET	Electrolytic

ECE□N ... Non polar electrolytic
ECQS..... Polystyrene
ECS□ Tantalum
OCS Tantalum

NOTE: Δ indicates that only parts specified by the manufacturer be used for safety.

Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.
R124	ERQ14AJ151	R406	ERD25FJ100	C205, 206	ECEA1CS330	Q13, 14, 15, 16		
R125	ERD25FJ103	R407, 408	ERD25FJ390	C207, 208	ECCD1H470K	25C945		
R126	ERD25FJ332	R409, 410	ERD25FJ472	C209, 210, 211, 212	ECEA1H510K	25A999E		
R127, 128	ERD25TJ5684	R411	ERD25FJ683		ECEA1H510K	Q101, 102, 103		
R129	ERD25FJ102	R412	ERD25FJ392	C213	ECEA1H510K	25C945		
R130	ERD25FJ472	R413	ERD25FJ272	C214	ECEA1H510K	Q201, 202, 203, 204		
R201, 202	ERD25FJ391	R414	ERD25TJ104	C215, 216	ECEA1AS221	25C1327		
R203, 204	ERD25FJ101	R415	ERD25TJ474	C217, 218	ECEA50MR33R	Q205, 206	25D592NCS	
R205, 206	ERD25FJ273			C221, 222	ECQMIH273JZ	Q207, 208, 209, 210		
R207, 208	ERD25CKF1003	R416	ERD25TJ393	C223, 224, 225, 226		25C945		
R209, 210	ERD25FJ560	R417	ERD25TJ683		ECEA1H510K	Q401, 402	25C592NCS	
R211, 212	ERD25FJ382	R419, 420	ERD25FJ273	C227, 228	ECQMIH472JZ	Q403	25D946	
R213, 214	ERD25CKF1003	R421	ERD25TJ104		ECQMIH562JZ	Q404, 405, 406, 407, 408		
R215, 216	ERD25FJ472	R422	ERQ14AJ101P	C229, 230	ECQMIH473KZ	25C945		
R217, 218	ERD25FJ821	R423	ERD25FJ562	C233, 234		Q409, 410, 411		
R221, 222, 223, 224		R424	ERD25FJ100			25A999E		
R225, 226	ERD25FJ102	R425	ERD25TJ473	C235, 236, 237, 238		25D794P		
R227, 228	ERD25TJ394	R426, 427	ERD25FJ102		ECEA1H510K			
R229, 230	ERD25FJ332	R428	ERD25FJ561	C239, 240	ECQMIH510K			
R231, 232	ERD25FJ181	R429	ERD25TJ823	C241, 242	ECEA50ZR33	INTEGRATED CIRCUITS		
R233, 236	ERD25TJ473	R430	ERD25FJ681	C243, 244	ECCD1H151KB	IC1, 2, 3, 4	NE646B	
R237, 238	ERD25TJ684	R431	ERD25FJ222	C245, 246	ECEA50ZR47			
R239, 240	ERD25TJ2003	R432, 433	ERD25FJ103	C247, 248	ECCD1H681KB	IC5	AN6552	
R241, 242	ERD25TJ6274	R434	ERD25FJ562	C249, 250	ECEA1CS330	IC6	AN6870	
R243, 244	ERD25TJ683	R435	ERG1ANJ121	C251, 252	ECEA1H510K	COMBINATION PARTS		
R247, 248	ERD25FJ472	R436	ERD25TJ223	C253, 254	ECEA50ZR33	CR1, 2	EXRPF681K472	
R249, 250	ERD25FJ1231	R501	ERQ14AJ100P	C255, 256	ECCD1H151KB	CR3, 4	EXRPI22K473	
R251, 252, 253, 254		R502, 504	ERD25FJ681	C257, 258	ECQMIH183JZ	CR01, 202	EXRPF681K472	
R255, 256	ERD25FJ103	R503, 504		C259, 260	ECQMIH822KZ	CR203, 204, 205, 206		
R257, 258	ERD25FJ393		ERQ14AJ181P	C263, 264	ECQMIH333JZ	EXRPI22K473		
R259, 260	ERD25TJ823	R601	ERD25FJ472	C265, 266	ECQMIH273KZ	CR207, 208	EXRPI22K222	
		R602	ERD25FJ472	C267, 268	ECQMIH683KZ			

[illegible]


		CAPACITORS					
J202	R287, 288	ERD25FJ470		C409	ECEA2AS2R2	L301	QLB0158
J120	R289, 290	ERD25FJ821	C1.2	C410	ECEA1HS100		
J330	R291, 292	ERD25FJ182	C3.4	C412, 413	ECEA1HS470		S
J683	R293, 294	ERD25FJ102	C5.6	C414	ECEA1HS100	S1, 2.3	QSWY305
J223			C7.8	C415	ECEA1JS4R7		
J104	R301	ERD25FJ331	C9.10	C416	ECEA1VS221	S4	QSR6402A
G2702	R303, 304	ERD25FJ152	C13.14	C417	ECEA2AS2R2	S5	EVOPAR11K
J153	R305, 306	ERD25FJ472	C15.16	C418	ECQM1H183KZ	S6	QSB0178
J180	R307, 308	ERD25FJ151	C17.18	C501	ECEA1VS102		
J561	R309, 310	ERD25TJ224	C19.20	C502	ECKD1H103P	S7, 8, 9	QSB0253M
	R311, 312	ERD25FJ103	C21.22			S10	Δ RSH1B04ZAS
	R313	ERD25FJ152	C23	C503 Δ	ECEA1ES221	Δ	QSR1407H
	R314	ERG1ANJ151	C24	C504 Δ	ECEA1ES331		
J223	R315, 316	ERD25FJ102	C25, 26	C505	ECKD1H103P		
G1003	R401, 402	ERD25FJ100	C27, 28	C506 Δ	ECEA1VS102		
J331			C29, 30	C507	ECEA1ES222	J1	QJA0257H
J224			C31, 32	C508	ECKD1H103P	J2	QJA0255H
J102	R403	ERD25FJ1R0	C33, 34			J3	QEJ5002H
	R404, 405	ERD25TJ683					

level controls ... MAX	C39, 38	ECC81H152RB	DIODES & RECTIFIERS		F1	Δ	XBAQ0009
level control ... MAX	C35, 36	ECEA1HS100			F2	Δ	XBAQ0003
	C37, 37	ECQM1H472JZ	D1, 2	MA161	F3	Δ	XBAQ0006
	C39, 40	ECEA1HS100	D101, 102	MA161			
			D103	MV121			
	C41, 42	ECQM1H562JZ	D104	MA161			
More than 47 dB	C45, 46	ECQM1H473KZ	D201, 202	MA161			
(without NAB filter)	C47, 48	ECEA1HS100	D401, 402, 403, 404, 405, 406,	MA161			
	C49, 50	ECQV05104JZ	407, 408	MA161			
	C51, 52	ECEA502R33	D409	RD22E81			
Less than 2.3%	C53, 54	ECEA2A53R3	D501 Δ	RD22E81			
(Normal)	C55	ECEA1ES221	D502, 503, 504, 505	Δ SM112			
	C57, 58	ECEA2A53R3	D601	LD001UR			
Less than 3.3%	C59, 60	ECEA2A5010	D602	LD001GG			
e-Cr, CrO ₂ and Metal)	C61, 62	ECEA1HS100	D603	LD001YY			
			TRANSISTORS				
	C63, 64	ECEA1CS221					
	C65	ECEA1ES101	Q1, 2	2SC1844E			
	C101, 102	ECEA502R22	Q3, 4	2SC1327			
	C103, 104	ECEA2A53R3	Q5, 6, 7, 8, 9, 10	2SC245			
	C105	ECQM1H473KZ	Q11, 12	2SD592NCS			
	C106	ECQV05104JZ					
	C107	ECEA1JS4R7					
	C108	ECEA1HS100					
	C201, 202	ECEA16M10R					
	C203, 204	ECC81H102KR					


Ref. No.	Part No.	Part Name & Description
<u>TRANSFORMER</u>		
T501	△ QLPD51EME	AC Power Transformer
<u>COILS</u>		
L1, 2	QLQX1032W	Bias Trap Coil (for Recording System)
L201, 202	QLM9Z6K	Multiplex Filter
L203, 204	QLQC2721K	Peaking Coil
L205, 206	QLQX1032W	Bias Trap Coil (for Recording System)
L301	QLB0158	Bias Oscillation Coil
<u>SWITCHES</u>		
S1, 2, 3	QSWY305	Push Switch (Dolby NR, Monitor Selector, Input Selector)
S4	QSR6402A	Rotary Switch (Tape Selector)
S5	EQOPAR11K	Push Switch (Rec-Mute)
S6	QSB0178	Leaf Switch (Record/Playback Selector)
S7, 8, 9	QSB0253M	Leaf Switch
S10	RSH1B04ZAS	Push Switch (Power ON/OFF)
S11	△ QSR1407H	Rotary Switch (AC Power Voltage Selector)
<u>JACKS</u>		
J1	QJA0257H	Microphone Jack
J2	QJA0255H	Headphones Jack
J3	QEJ5002H	Jack Board Assembly
<u>FUSES</u>		
F1	△ XBAQ0009	Fuse (T 800 mA)
F2	△ XBAQ0003	Fuse (T 500 mA)
F3	△ XBAQ0006	Fuse (T 315 mA)

CIRCUIT BOARDS


MAIN CIRCUIT BOARD



FL METER CIRCUIT BOARD



POWER SUPPLY CIRCUIT BOARD



NOTES:

- The circuit shown in [redacted] on the conductor is +B (bias) circuit.
- The circuit shown in [redacted] on the conductor indicates printed circuit on the back side of the printed circuit board.
- Values indicated in [redacted] are DC voltage between the ground and electrical parts.
- The voltage indicates are measured during record mode.


<p>Carbon</p> <p>Metal-oxide</p> <p>Metal-oxide</p> <p>Metal-film</p> <p>Metal-film</p> <p>Fuse type metallic</p> <p>Solid</p> <p>Cement</p>	<p>CAPACITORS</p> <p>ECG Ceramic</p> <p>ECK Ceramic</p> <p>ECC Ceramic</p> <p>ECF Ceramic</p> <p>ECQM Polyester film</p> <p>EQE Polyester film</p> <p>EQF Polypropylene</p> <p>ECE Electrolytic</p>	<p>ECE Non polar electrolytic</p> <p>EQS Polystyrene</p> <p>ECS Tantalum</p> <p>QCS Tantalum</p>
--	---	--

NOTE: Δ indicates that only parts specified by the manufacturer be used for safety.


Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.	Ref. No.	Part No.
RS	R124	ERQ14AJ151	R406	ERD25FJ100	C205, 206	ECEA1CS330	Q13, 14, 15, 16	2SC945
FJ101	R125	ERD25FJ103	R407, 408	ERD25FJ390	C207, 208	ECCD1H470K	Q17, 18	2SA999E
FJ560	R126	ERD25FJ332	R409, 410	ERD25FJ472	C209, 210, 211, 212	ECEA1HS100	Q201, 202, 203, 204	2SC945
CKF1003	R127, 128	ERD25TJ684	R411	ERD25FJ683	C213	ECEA1ES470	Q205, 206	2SD592NCS
FJ472	R129	ERD25FJ102	R412	ERD25FJ392	C214	ECEA1CS331	Q207, 208, 209, 210	2SC945
CKF1003	R201, 202	ERD25FJ392	R413	ERD25FJ272	C215, 216	ECEA1AS221	Q401, 402	2SC592NCS
FJ472	R203, 204	ERD25FJ101	R414	ERD25TJ104	C217, 218	ECEA50MR33R	Q403	2SD946
FJ821	R205, 206	ERD25FJ273	R415	ERD25TJ474	C221, 222	EQQM1H273JZ	Q404, 405, 406, 407, 408	2SC945
TJ124	R207, 208	ERD25OKF1003	R416	ERD25TJ393	C223, 224, 225, 226	ECEA1HS100	Q409, 410, 411	2SA999E
TJ393	R209, 210	ERD25FJ560	R417	ERD25TJ683	C227, 228	EQQM1H472JZ	Q501, 502	2SD794P
FJ472	R211, 212	ERD25FJ822	R419, 420	ERD25FJ273	C239, 240	ECEA1HS100		
FJ562	R213, 214	ERD25OKF1003	R421	ERD25TJ104	C241, 242	ECEA50Z33		
TJ104	R215, 216	ERD25FJ472	R422	ERQ14AJ101P	C243, 244	ECKD1H151KB		
	R217, 218	ERD25FJ821	R423	ERD25FJ562	C245, 246	ECEA50Z33		
			R424	ERD25FJ100	C247, 248	ECKD1H681K		
			R425	ERD25TJ473	C249, 250	ECEA1CS330		
FJ102	R221, 222, 223, 224		R426, 427	ERD25FJ102	C251, 252	ECEA1HS100		
FJ272	R225, 226	ERD25TJ394	R428	ERD25FJ561	C253, 254	ECEA50Z33		
NJ151	R227, 228	ERD25FJ332			C255, 256	ECKD1H151KB		
FJ682	R229, 230	ERD25FJ181	R429	ERD25TJ823	C257, 258	EQQM1H83JZ		
FJ102	R235, 236	ERD25TJ473	R430	ERD25FJ681	C259, 260	EQQM1H822KZ		
FJ332	R237, 238	ERD25TJ684	R431	ERD25FJ222	C263, 264	EQQM1H333JZ		
TJ684	R239, 240	ERD25TJ203	R432, 433	ERD25FJ103	C265, 266	EQQM1H273KZ		
TJ473	R241, 242	ERD25TJ274	R434	ERD25FJ562	C267, 268	EQQM1H683KZ		
FJ181	R243, 244	ERD25TJ683	R435	ERG1ANJ121	C269, 270	EQQM1H273KZ		
TG2003	R247, 248	ERD25FJ472	R436	ERD25TJ223	C271, 272	EQQM1H393KZ		
TJ274	R249, 250	ERD25TJ123	R501	ERQ14AJ100P	C273, 274	EQQM1H273KZ		
TJ683			R502 Δ	ERD25FJ681				
FJ391	R251, 252, 253, 254		R503, 504	ERQ14AJ181P				
FJ152								
FJ472	R255, 256	ERD25TJ393						
TJ154	R257, 258	ERD25TJ823						
TJ333	R259, 260	ERD25TJ183	R601	ERD25FJ472				
FJ182	R261, 262	ERD25TJ563	R602	ERD50FJ152				
	R263, 264	ERD25TJ104	R603	ERG12ANJ182				
FJ561	R265, 266, 267, 268							
FJ181								
FJ152	R269, 270	ERD25TJ124						
FJ332	R271, 272	ERD25TJ104						
FJ104								
FJ392	R273, 274	ERD25FJ222						
FJ102	R275, 276	ERD25TJ103						
FJ104	R277, 278	ERD25TJ393						
TJ473	R279, 280	ERD25FJ332						
FJ102	R281, 282	ERD25FJ330						
	R283, 284, 285, 286							
J220	R287, 288	ERD25FJ680						
J102	R289, 290	ERD25FJ821						
J330	R291, 292	ERD25FJ182						
J683	R293, 294	ERD25FJ102						
J223								
J104	R301	ERD25FJ331						
G2702	R303, 304	ERD25FJ152						
J153	R305, 306	ERD25FJ472						
J180	R307, 308	ERD25FJ151						
J561	R309, 310	ERD25TJ224						
	R311, 312	ERD25FJ103						
	R313	ERD25FJ152						
J223	R314	ERG1ANJ151						
G1003	R315, 316	ERD25FJ102						
J331	R401, 402	ERD25FJ100						
J224								
J102	R403	ERD25FJ180						
J822	R404, 405	ERD25TJ683						

CIRCUIT BOARDS


MAIN CIRCUIT BOARD



FL METER CIRCUIT BOARD




POWER SUPPLY CIRCUIT BOARD



NOTES:


- The circuit shown in on the conductor is +B (bias) circuit.
- The circuit shown in on the conductor indicates printed circuit on the back side of the printed circuit board.
- Values indicated in are DC voltage between the ground and electrical parts.
- The voltage indicates are measured during record mode.

WIRING CONNECTION DIAGRAM




MECHA

(FRONT VIEW




WH
ins
RS

Ref. No.	Part
M1	QBP1874
M2	QDG120
M3	QDG1202
M4	QDB133
M5	QDR1139
M6	QMF2118
M7	QML358
M8	QML358
M9	QML358
M10	QML358
M11	QML359
M12	QML360
M13	QML360
M14	QML360
M15	QML399
M16	QMR182
M17	QMR182
M18	QMR182
M19	QMR182
M20	QMZ1235
M21	QBC135
M22	QBT168
M23	QBT189
M24	QBN173




MECHANICAL PARTS LOCATION (FRONT VIEW)



When servicing this mechanism unit, refer to the disassembly notes and assembly instructions described in the service manuals of RS-M51, RS-M13, RS-M14 and RS-M04 (RS-M24 mechanism series).

Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
MECHANICAL PARTS			M25	QBN1742	Pressure Roller Release Spring	M49-1	QBW2049	Poly Washer
M1	QBP1874	Cassette Pressure Spring	M26	QBN1744	Sub Gear Spring	M49-2	QBW2026	Washer
M2	QDG1201	Main Gear	M27	QBN1802	Main Gear Spring	M50	QXD1143	Takeup Reel Table Assembly
M3	QDG1202	Sub Gear	M28	QBN1746	Auto-Stop Lever Spring	M51	QXL1382	Idler Lever Assembly
M4	QMB1336	Supply Reel Table Hub	M29	QBN1747	Connection Spring	M52	QXI0111	Takeup Idler Assembly
M5	QDR1139	Supply Reel Table	M30	QBS1128	Lock Pin	M53	QBT1893	Takeup Idler Spring
M6	QMF2118	Fast Forward Arm Bracket	M31	QBC1372	Reel Table Spring	M54	QXI0113	Fast Forward Idler Assembly
M7	QML3581	Sub Control Lever	M32	QBW2008	Poly Washer 2φ	M55	QXI0112	Rewind Idler Assembly
M8	QML3583	Main Control Lever	M33	XUB4FT	Stop Ring 4φ	M56	QXL1383	Fast Forward Arm Assembly
M9	QML3584	Record Operation Lever	M34	XUB3FT	Stop Ring 3φ	M57	QBC1343	Head Spring
M10	QML3586	Head Base Plate Lift Lever	M35	QBW2012	Poly Washer	M58	QTD1292	Cord Clasper
M11	QML3594	Auto-Stop Release Arm	M36	QXL1354	Sub Lever Assembly	M59	QXA1084	Erase Head Base Plate Assembly
M12	QML3603	Erase Safety Lever	M37	QXL1355	Main Lever Assembly	M60	QNO1094	Nut (Erase Head Adjustment)
M13	QML3604	Auto-Stop Driving Lever	M38	QML3582	Pause Lock Lever	M61	QBN1788	Back Tension Spring
M14	QML3605	Auto-Stop Detection Lever	M39	QBT1896	Lever Release Spring	M62	QML3591	Brake Arm
M15	QML3592	Change Lever	M40	QXL1381	Pressure Roller Assembly	M63	QML1240	Sub Head Base Plate
M16	QMR1820	Record Rod	M41	QBN1743	Pressure Roller Spring	M64	QMN2550	Roller
M17	QMR1821	Auto-Stop Connection Rod	M42	QML3588	Fast Forward Lever	M65	QDK1017	Steel Ball 2φ
M18	QMR1822	Eject Rod	M43	QBN1748	Fast Forward Spring	M66	QBP1873	Head Base Plate Pressure Spring
M19	QMR1824	Control Rod	M44	QMA3861	Plunger Angle	M67	QBT1597	Brake Arm Spring
M20	QML2139	Flywheel Thrust Retainer	M45	QXK2388	Head Base Plate Assembly	M68	QBT1892	Head Release Spring
M21	QBC1357	Lock Pin Pressure Spring	M46	QXK2388	Head Spacer	M69	QMA3858	Pressure Roller Adjustment Plate
M22	QBT1682	Auto-Stop Connection Rod Spring	M47	QBN1740	Head Pressure Spring	M70	QXG1047	Takeup Gear Assembly
M23	QBT1894	Main Lever Spring	M48	QBCA0008	Head Spring	M71	QXU0170	Motor Assembly
M24	QBN1739	Selection Lever Spring	M49	QXF0164	Flywheel Assembly	M72	QXK2286	Sub Chassis Assembly

(REAR VIEW)




Ref. No.	Part No.	Part Name & Description	Ref. No.	Part No.	Part Name & Description
M73	QDG1199	Auto-Stop Gear	M97	XTN3+24B	Tapping Screw $\phi 3 \times 24$
M74	QDG1200	Cam Gear	M98	XSN26+3	Screw $\phi 2.6 \times 3$
M75	QDP1823	Connection Pulley	M99	XSN2+3	Screw $\phi 2 \times 3$
M76	QDB0281	Capstan Belt	M100	XTN26+6BFZ	Tapping Screw $\phi 2.6 \times 6$
M77	QDB0274	Takeup Belt	M101	XTS26+6B	Tapping Screw $\phi 2.6 \times 6$
M78	QDB0273	Fast Forward Belt	M102	QXA1086	Sub Angle Assembly
M79	QXL1360	Record/Playback Selection Arm Assembly	M103	QMA4011	Switch Angle
M80	QML3580	Record/Playback Selection Lever	M104	QBN1741	Change Lever Spring
M81	QBT1895	Record/Playback Selection Lever Spring			
M82	QXP0607	Fast Forward Connection Pulley Assembly			
M83	QMK1838	Upper Base Plate			
M85	QDP1828	Fast Forward Pulley			
M86	QXH0347	Chassis Cover Assembly			
M87	QXC0060	Tape Counter			
M88	QDB0240	Counter Belt			
M89	QMA3860	Counter Angle			
M90	XSN2+10	Screw $\phi 2 \times 10$			
M91	XWG2	Washer 2 ϕ			
M92	XTN2+6B	Tapping Screw $\phi 2 \times 6$			
M93	XTN26+6B	Tapping Screw $\phi 2.6 \times 6$			
M94	XTN26+10B	Tapping Screw $\phi 2.6 \times 10$			
M95	XTN26+12B	Tapping Screw $\phi 2.6 \times 12$			
M96	XTN3+10B	Tapping Screw $\phi 3 \times 10$			

SPECIFICATIONS

Pressure of pressure roller	350 ± 50 g
Takeup tension * Use cassette torque meter ...QZZSRKCT	$45 + 15$ $- 10$ g-cm
Wow and flutter; (JIS) * Use test tape ...QZZCWAT	Less than 0.06% (WRMS)

CABINET PARTS LOCATION



Ref. No.	Part No.	Part Name & Description
CABINET PARTS		
G1	QYPM0042 "Silver Type"	Front Panel Assembly
	QYPM0042K "Black Type"	"
G1-1	QGOM0037	Rec-Mute Button
G2	QYFM0047 "Silver Type"	Cassette Lid Assembly
	QYFM0047K "Black Type"	"
G3	QGCM0036	Bottom Cover
G4	QKA1083	Rubber Foot
G5	QYT0586 "Silver Type"	Volume Knob-A Assembly
	QYT0586K "Black Type"	"
G6	QYT0587 "Silver Type"	Volume Knob-B Assembly
	QYT0587K "Black Type"	"
G7	QGO1692N "Silver Type"	Push Button (Power ON/OFF)
	QGO1692K "Black Type"	"
G8	QGO1694N "Silver Type"	Push Button (Monitor/Dolby NR/ Input Select)
	QGO1694K "Black Type"	"
G9	QGT1515 "Silver Type"	Control Knob (Tape Select/Output Level)
	QGT1515K "Black Type"	"
G10	QYKM0008 "Silver Type"	Meter Cover
	QYKM0008K "Black Type"	"
G11	QKJM0045 "Silver Type"	Meter Filter
	QKJM0045Y "Black Type"	"
G12	QGC1182 "Silver Type"	Case Cover
	QGC1182K "Black Type"	"
G13	XTN2+6B	Tapping Screw $\pm 2 \times 6$
G14	XTB4+10BFN "Silver Type"	Tapping Screw $\pm 4 \times 10$
	XTB4+10BFZ "Black Type"	"
G15	XTS3+10B	Tapping Screw $\pm 3 \times 10$
G16	XTN3+10B	"
G17	QH01299	Step Screw
G18	QGS0125	Main Name Plate
*For all European areas except United Kingdom.		
	QGS0126	"
*For United Kingdom.		
G19	QKMM0032K	Main Case
G20	QXL1363	Eject Button Assembly
G21	QXL1364	Record Button Assembly
G22	QXL1365	Rewind/Review Button Assembly
G23	QXL1366	Fast Forward/Cue Button Assembly
G24	QXL1367	Playback Button Assembly
G25	QXL1368	Stop Button Assembly
G26	QXL1369	Pause Button Assembly
G27	QMN2554	Operation Lever Shaft
G28	QBT1597	Obstruction Rod Spring
G29	QMR1823	Obstruction Rod
G30	QBP1875	Operation Lever Spring
G31	QXA1044	Operation Button Angle Assembly
G32	QDG1102	Holder Gear
G33	QBW2082	Snap Ring
G34	QML3593	Lock Arm
G35	QBP1900	Holder Spring
G36	QBN7008	Eject Spring
G37	XUB5FT	Stop Ring 5 ϕ
G38	QKFM6005K	Cassette Holder
G39	XTN26+6B	Tapping Screw $\pm 2.6 \times 6$
ACCESSORIES		
A1	RP023A	Connection Cord
A2	QQT2874	Instruction Book
*For all European areas except United Kingdom.		
	QQT2875	"
*For United Kingdom.		
PACKINGS		
P1	QPNM0154	Inside Carton
P2	QPAM0042	Cushion-R
P3	QPAM0043	Cushion-L
P4	XZB40X60A02	Poly Bag
P5	QPG1985	Pad

RS-M260 FRANCAIS

MESURES ET REGLAGES

NOTA: Pour garder l'appareil en bon état de marche, positionner les commutateurs à levier et les commandes dans les positions suivantes, sauf indication contraire.





















- Vérifiez que les têtes soient propres.
- Vérifiez que le cabestan et le galet-presseur soient propres.
- Température ambiante admissible: 20±5°C.
- Sélecteur de bande: Normal
- Commutateur de contrôle: Position bande
- Commande de niveau: MAX
- Commande de niveau de sortie: MAX
- Sélecteur de Dolby: OUT
- Commutateur de test de crête: LINE

SECTION	MESURES ET REGLAGES
A Réglage de la position de la tête Condition: * Le mode de lecture et pause	Il y a une plaque de réglage de la tête pour ajuster le contact de bande de la tête en mode de repérage avant ou arrière. 1. Appuyer sur le bouton de lecture (PLAY) et le bouton de pause. 2. Mesurer l'espace qui sépare le galet presseur du cabestan. Valeur normale: 0.5±0.3mm 3. Si la valeur mesurée se trouve hors tolérances, desserrer la vis A, et glisser la plaque de réglage de la tête dans la direction de la flèche B pour effectuer le réglage (Voir Fig. 2).
B Azimutage de tête Condition: * Position lecture Equipement: * Voltmètre électronique * Oscilloscope * Bande étalon (azimutage)...QZZCFM * Bande étalon (Fenêtre de passage de la bande avec miroir) ...QZZCRD	Réglage de la tête multiple 1. Branchez les appareils comme ci-dessous. (Voir Fig. 3). 2. Lisez la bande étalon d'azimutage (QZZCFM, 8kHz). 3. Réglez la vis d'orientation (B) Fig. 4, de la tête d'enregistrement/lecture pour obtenir le niveau maximal à la sortie LINE OUT. 4. Mesurez les deux canaux, et ajustez les niveaux à égalité de tension de sortie. 5. Après réglage, bloquez la vis par une goutte de vernis.
C Réglage de la hauteur de la tête d'effacement Condition: * Position lecture Equipement: * Bande étalon (Fenêtre de passage de la bande avec miroir) ...QZZCRD	1. Retirer les vis (D) et (E) pour remplacer la tête de lecture. (L'écrou (C) étant conçu pour le réglage de la hauteur de la tête d'effacement pour maintenir la performance, ne pas le retirer.) 2. Après avoir remplacé la tête d'effacement, procéder à la vérification du bon déroulement de la bande en écoutant la bande d'essai QZZCRD. Pour tout problème de déroulement de la bande, régler selon la procédure ci-dessous. Réglage 1. Ajuster l'écrou (C) montré à la fig. 5 de sorte que la bande passe correctement sur le guide de la tête d'effacement. 2. Le réglage terminé, bloquer l'écrou (C) avec du vernis.
D Vitesse de défilement Condition: * Position lecture Equipement: * Compteur électronique numérique ou fréquencemètre numérique * Bande étalon...QZZCWAT	Précision de la vitesse de défilement 1. Branchez les appareils comme ci-dessous. (Voir fig. 6). 2. Lisez la bande étalon (QZZCWAT, 3000Hz) et appliquez le signal de sortie au fréquencemètre. 3. Mesurez sa fréquence. 4. Sur la base de 3000Hz, déterminez la valeur à l'aide de la formule. $\text{Précision de vitesse} = \frac{f - 3000}{3000} \times 100(\%)$ avec f = valeur mesurée. 5. Effectuez la mesure sur la partie médiane de la bande. Valeur normale: ±1.5% Méthode de réglage 1. Lisez la bande étalon (milieu). 2,3. Ajustez la vis de réglage de vitesse VR indiquée fig. 1 pour que la fréquence devienne égale à 3000Hz. Nota: Utiliser un tournevis non métallique pour régler la vitesse de bande de cet appareil avec précision. Fluctuations de vitesse de défilement Faites les mesures de la même façon que ci-dessus (au début, au milieu et en fin de bande) et déterminez la différence entre les valeurs maximale et minimale, puis calculez comme suit.

SECTION	MESURES ET REGLAGES																																								
	<div>Fluctuations de vitesse = $\frac{f_1 - f_2}{3000} \times 100(\%)$</div> <div>$f_1$ = valeur maximale f_2 = valeur minimale</div> <div>Valeur normale: monis de 1%</div>																																								
<div>E Réponse en fréquence à la lecture</div> <div>Condition:</div> <div><ul style="list-style-type: none">* Position lecture* Sélecteur de bande ...position Normal* Commande de niveau de sortie...MAX.</div> <div>Equipement:</div> <div><ul style="list-style-type: none">* Voltmètre électronique* Oscilloscope* Bande étalon...QZZCFM</div>	<div><div>1. Branchez les appareils comme ci-dessous (Voir Fig. 3).</div><div>2. Placez l'appareil en position lecture.</div><div>3. Lisez la bande étalon de courbe de réponse (QZZCFM).</div><div>4. Mesurez les niveaux de sortie à 315Hz, 12.5kHz, 8kHz, 250Hz, 125Hz et 63Hz et comparez chaque niveau de sortie avec celui de la fréquence étalon de 315Hz, sur la borne LINE OUT.</div><div>5. Effectuez la mesure sur les deux canaux.</div><div>6. Vérifiez que les valeurs mesurées se situent à l'intérieur du gabarit de courbe de réponse. (Vori Fig. 7).</div></div> <div>Réglage</div> <div><div>1. Si la valeur mesurée se trouve hors tolérances dans la gamme des fréquences élevées, les points de connexion PCB (a) (canal gauche) et (a') (canal droit) doivent être court-circuités. Dans ce cas, les points de connexion (b) (canal gauche) et (b') (canal droit) doivent être ouverts.</div><div>2. Procéder aux mêmes mesures données aux étapes 2 à 6 de la section "Mesure" ci-dessus.</div><div>3. Si la valeur mesurée diminue dans la gamme des hautes fréquences, comme montré dans la Fig. 8, les points de connexion (b) (canal gauche) et (b') (canal droit) de la plaquette à câblage imprimé devraient être courtcircuités (Voir Fig. 12).</div></div> <div>Valeur de compensation</div> <table><tr><td>4kHz</td><td>6kHz</td><td>8kHz</td><td>10kHz</td><td>12.5kHz</td></tr><tr><td>Autour de +0.3dB</td><td>Autour de +0.5dB</td><td>Autour de +0.7dB</td><td>Autour de +0.7dB</td><td>Autour de +0.6dB</td></tr></table> <div><div>4. Si la valeur mesurée augmente dans la gamme des fréquences élevées, voir figure 9, les points de connexion (a) (canal gauche) et (a') (canal droit) doivent être ouverts. Les points de connexion (b) (canal gauche) et (b') (canal droit) doivent être court-circuités.</div></div> <table><tr><td>4kHz</td><td>6kHz</td><td>8kHz</td><td>10kHz</td><td>12.5kHz</td></tr><tr><td>Autour de 0dB</td><td>Autour de -0.3dB</td><td>Autour de -0.4dB</td><td>Autour de -0.5dB</td><td>Autour de -0.9dB</td></tr></table> <div><div>5. Si la valeur mesurée diminue à la gamme des moyennes fréquences, comme montré à la Fig. 10, les points de branchement (c) et (c') de la plaquette à câblage imprimé doivent être ouverts (Voir Fig. 12).</div></div> <div>Valeur de compensation</div> <table><tr><td>700Hz</td><td>1kHz</td><td>2kHz</td><td>4kHz</td><td>10kHz</td></tr><tr><td>Autour de +0.2dB</td><td>Autour de +0.4dB</td><td>Autour de +0.7dB</td><td>Autour de +0.9dB</td><td>Autour de +1.2dB</td></tr></table> <div><div>6. Si la valeur mesurée augmente à la gamme des moyennes fréquences, comme montré à la Fig. 11, les points de branchement (c) et (c') doivent être court-circuités (Voir Fig. 12).</div></div> <div>Valeur de compensation</div> <table><tr><td>700Hz</td><td>1kHz</td><td>2kHz</td><td>4kHz</td><td>10kHz</td></tr><tr><td>Autour de -0.2dB</td><td>Autour de -0.4dB</td><td>Autour de -0.7dB</td><td>Autour de -0.9dB</td><td>Autour de -0.9dB</td></tr></table>	4kHz	6kHz	8kHz	10kHz	12.5kHz	Autour de +0.3dB	Autour de +0.5dB	Autour de +0.7dB	Autour de +0.7dB	Autour de +0.6dB	4kHz	6kHz	8kHz	10kHz	12.5kHz	Autour de 0dB	Autour de -0.3dB	Autour de -0.4dB	Autour de -0.5dB	Autour de -0.9dB	700Hz	1kHz	2kHz	4kHz	10kHz	Autour de +0.2dB	Autour de +0.4dB	Autour de +0.7dB	Autour de +0.9dB	Autour de +1.2dB	700Hz	1kHz	2kHz	4kHz	10kHz	Autour de -0.2dB	Autour de -0.4dB	Autour de -0.7dB	Autour de -0.9dB	Autour de -0.9dB
4kHz	6kHz	8kHz	10kHz	12.5kHz																																					
Autour de +0.3dB	Autour de +0.5dB	Autour de +0.7dB	Autour de +0.7dB	Autour de +0.6dB																																					
4kHz	6kHz	8kHz	10kHz	12.5kHz																																					
Autour de 0dB	Autour de -0.3dB	Autour de -0.4dB	Autour de -0.5dB	Autour de -0.9dB																																					
700Hz	1kHz	2kHz	4kHz	10kHz																																					
Autour de +0.2dB	Autour de +0.4dB	Autour de +0.7dB	Autour de +0.9dB	Autour de +1.2dB																																					
700Hz	1kHz	2kHz	4kHz	10kHz																																					
Autour de -0.2dB	Autour de -0.4dB	Autour de -0.7dB	Autour de -0.9dB	Autour de -0.9dB																																					
<div>F Gain à la lecture</div> <div>Condition:</div> <div><ul style="list-style-type: none">* Position lecture* Sélecteur de bande ...position Normal* Commande de niveau de sortie...MAX.</div> <div>Equipement:</div> <div><ul style="list-style-type: none">* Voltmètre électronique* Oscilloscope* Bande étalon...QZZCFM</div>	<div><div>1. Branchez les appareils comme ci-dessous (Voir Fig. 3).</div><div>2. Lisez la partie "niveau standard" de la bande étalon (QZZCFM, 315Hz) et mesurez le niveau de sortie, avec le voltmètre électronique, sur le jack LINE OUT.</div><div>3. Effectuez les mesures sur les deux canaux.</div></div> <div>Valeur normale: Autour de 0.7V</div> <div>Réglage</div> <div><div>1. Si la valeur mesurée n'est pas correct, réglez VR1 (canal gauche) et VR2 (canal droit) (Voir Fig. 1).</div><div>2. Après réglage, vérifiez à nouveau la "E" réponse en fréquence à la lecture".</div></div>																																								



SECTION	MESURES ET REGLAGES
G Fuites de Prémagnétisation Condition: * Position enregistrement * Sélecteur de bande ...position Normal Equipement: * Voltmètre électronique * Oscilloscope	Réglage (Pour l'amplificateur d'enregistrement) 1. Branchez les appareils comme ci-dessous. 2. Placez l'appareil en position enregistrement. 3. Réglez les bobines de la trappe L204 (canal droit) pour que la mesure soit correcte. Réglage (Pour l'amplificateur de reproduction) 1. Branchez les appareils comme ci-dessous. 2. Placer l'appareil en mode d'enregistrement. 3. Régler les bobines bouchon L1 (canal droit) de façon à minimiser les valeurs de sortie LINE-OUT.
H Courant d'effacement Condition: * Position enregistrement * Sélecteur de bande ...position Metal Equipement: * Voltmètre électronique * Oscilloscope	1. Branchez les appareils comme ci-dessous. 2. Placer l'appareil en mode d'enregistrement. 3. Déterminer le courant d'effacement (A) $\text{Tension aux bornes de la bobine} = \frac{\text{Valeur lue sur voltmètre}}{1(\Omega)}$ Valeur normale: 100 ± 20 mA 4. Si la valeur lue se trouve hors tolérances, réglez VR402 (canal gauche) et VR404 (canal droit) pour obtenir le courant d'effacement correct.
I Courant de prémagnétisation Condition: * Position enregistrement * Sélecteur de bande ...position Normal * Commande de niveau de sortie...MAX. Equipement: * Voltmètre électronique * Oscilloscope	1. Branchez les appareils selon la Fig. 12. 2. Placez l'appareil en position enregistrement. 3. Lisez la tension sur le voltmètre électronique. $\text{Courant de prémagnétisation} = \frac{\text{Tension lue sur voltmètre}}{10(\Omega)}$ Valeur normale: 0.7±0.3mA 4. Réglez VR402 (canal gauche) et VR404 (canal droit) pour obtenir le courant de prémagnétisation correct. Valeur normale: 1.0±0.3mA (pour Fe-Cr) 1.6±0.3mA (pour Metal)
J Gain global Condition: * Positions enregistrement/lecture * Sélecteur de bande ...position Normal * Commande de niveau de sortie...MAX. * Niveaux d'entrée normaux MIC-72±3dB LINE IN-24±3dB Equipement: * Voltmètre électronique * Générateur AF * Atténuateur * Oscilloscope * Bande étalon vierge ...QZZCRA pour type de bande normale ...QZZCRY pour Fe-Cr ...QZZCRX pour CrO ₂ ...QZZCRZ pour Metal	1. Branchez les appareils comme sur la Fig. 13. 2. Mettre la cassette d'essai (QZZCRA) de la cassette. 3. Positionner l'appareil en mode d'enregistrement. 4. Appliquer un signal de 1kHz (-24dB) branché à l'ATT, à l'entrée LINE IN. 5. Régler le ATT de telle façon à ce que la tension de sortie devienne 0.7V. 6. Placez l'appareil en position enregistrement. 7. Effectuer la lecture d'une cassette de niveau de sortie à LINE OUT sur le jack. Valeur normal: Autour de 0.7V 8. Si la valeur lue se trouve hors tolérances, réglez VR204 (canal droit). 9. Recommencez à partir du palier (4). 10. Passer sur chaque position du sélecteur de bande. 11. Changer la bande d'essai sur Fe-Cr ou Metal (QZZCRZ). 12. Placez l'appareil en position enregistrement. 13. Effectuer la lecture d'une cassette de niveau de sortie à LINE OUT sur le jack. Valeur normal: 0.7V±1.5dB

	MESURES ET REGLAGES
	<p>Réglage (Pour l'amplificateur d'enregistrement)</p> <ol style="list-style-type: none"> 1. Branchez les appareils comme ci-dessous (voir Fig. 13). 2. Placez l'appareil en position enregistrement. 3. Réglez les bobines de la trappe L205 (canal gauche) et L206 (canal droit) pour que la mesure soit au minimum. (Voir Fig. 1). <p>Réglage (Pour l'amplificateur de reproduction)</p> <ol style="list-style-type: none"> 1. Branchez les appareils comme ci-dessous (Voir Fig. 14). 2. Placer l'appareil en mode d'enregistrement et amener le sélecteur de contrôle sonore à la position TAPE. 3. Régler les bobines bouchon L1 (canal gauche) et L2 (canal droit) de façon à minimiser les valeurs mesurées à la sortie de LINE-OUT.
	<ol style="list-style-type: none"> 1. Branchez les appareils comme ci-dessous (Voir Fig. 15). 2. Placer l'appareil en mode d'enregistrement et mesurer la tension au point d'essai 9. 3. Déterminer le courant d'effacement avec la formule suivante. <div style="text-align: center;"> $\text{Courant d'effacement (A)} = \frac{\text{Tension aux bornes de la résistance R403 (V)}}{1 (\Omega)}$ </div> <div style="border: 1px solid black; padding: 2px; margin: 5px auto; width: fit-content;"> Valeur normale: 100 + 20 - 5 mA (position Metal) </div> 4. Si la valeur lue se trouve hors tolérances, régler VR403.
	<ol style="list-style-type: none"> 1. Branchez les appareils selon la Fig. 16. 2. Placez l'appareil en position enregistrement, le sélecteur de bande sur "normal" (pour bande normale). 3. Lisez la tension sur le voltmètre électronique et calculez le courant de prémagnétisation selon la formule. <div style="text-align: center;"> $\text{Courant de prémagnétisation (A)} = \frac{\text{Tension lue sur voltm. élec. (V)}}{10 (\Omega)}$ </div> <div style="border: 1px solid black; padding: 2px; margin: 5px auto; width: fit-content;"> Valeur normale: 0.7±0.3mA (position Normal) </div> 4. Réglez VR402 (canal gauche) et VR401 (canal droit). 5. Positionner le sélecteur de bande sur chaque position. 6. Vérifiez si la valeur mesurée correspond à la norme. <div style="text-align: center; margin-top: 10px;"> 0.75±0.3mA (position Fe-Cr) Valeur normale: 1.0±0.3mA (position CrO₂) 1.6±0.3mA (position Metal) </div>
	<ol style="list-style-type: none"> 1. Branchez les appareils comme sur la Fig. 17. 2. Mettre la cassette d'essai (QZZCRA) en place dans le support de la cassette. 3. Positionner l'appareil en mode d'enregistrement, et le sélecteur de bande sur chaque position. 4. Appliquer un signal de 1kHz (-24dB) de l'oscillateur AF, branché à l'ATT, à l'entrée LINE IN. 5. Régler le ATT de telle façon à ce que le niveau de sortie à la fiche "LINE OUT" devienne 0.7V. 6. Placez l'appareil en position enregistrement. 7. Effectuer la lecture d'une cassette enregistrée, et mesurer le niveau de sortie à LINE OUT sur le voltmètre électronique à tubes. <div style="border: 1px solid black; padding: 2px; margin: 5px auto; width: fit-content;"> Valeur normal: Autour de 0.7V±1.5dB (position Normal) </div> 8. Si la valeur lue se trouve hors tolérances, régler VR203 (canal gauche), VR204 (canal droit). 9. Recommencez à partir du palier (4). 10. Passer sur chaque position du sélecteur de bande. 11. Changer la bande d'essai sur Fe-Cr (QZZCRY), CrO₂ (QZZCRX) ou Metal (QZZCRZ). 12. Placez l'appareil en position enregistrement. 13. Effectuer la lecture d'une cassette enregistrée, et mesurer le niveau de sortie à LINE OUT sur le voltmètre électronique à tubes. <div style="border: 1px solid black; padding: 2px; margin: 5px auto; width: fit-content;"> Valeur normal: 0.7V±1.5dB <div style="display: inline-block; vertical-align: middle; border-left: 1px solid black; padding-left: 5px; margin-left: 5px;"> position Fe-Cr position CrO₂ position Metal </div> </div>

SECTION	MESURES ET REGLAGES																																																																																										
	<div><div><div><div>14. Si la valeur mesurée ne correspond pas à la norme, réglez de la manière suivante.</div><div>15. Réglez l'amplification globale en court-circuitant ou en ouvrant le point du circuit imprimé à la Fig. 18, de telle manière que chacune des positions arrive autour de sa valeur normative.</div><div>16. Se référer au tableau suivant pour les valeurs des réglages des amplifications globales.</div></div><div><div><div>Position Fe-Cr (CANAL GAUCHE)</div><table><tr><th>AMPLIFICATION</th><th>POINT (d)</th><th>POINT (e)</th></tr><tr><td>FAIBLE</td><td>FERME</td><td>FERME</td></tr><tr><td></td><td>FERME</td><td>OUVERT</td></tr><tr><td></td><td>OUVERT</td><td>FERME</td></tr><tr><td>ELEVE</td><td>OUVERT</td><td>OUVERT</td></tr></table></div><div><div>Position CrO₂ (CANAL GAUCHE)</div><table><tr><th>AMPLIFICATION</th><th>POINT (f)</th><th>POINT (g)</th></tr><tr><td>FAIBLE</td><td>FERME</td><td>FERME</td></tr><tr><td></td><td>FERME</td><td>OUVERT</td></tr><tr><td></td><td>OUVERT</td><td>FERME</td></tr><tr><td>ELEVE</td><td>OUVERT</td><td>OUVERT</td></tr></table></div><div><div>Position Metal (CANAL GAUCHE)</div><table><tr><th>AMPLIFICATION</th><th>POINT (h)</th><th>POINT (i)</th></tr><tr><td>FAIBLE</td><td>FERME</td><td>FERME</td></tr><tr><td></td><td>FERME</td><td>OUVERT</td></tr><tr><td></td><td>OUVERT</td><td>FERME</td></tr><tr><td>ELEVE</td><td>OUVERT</td><td>OUVERT</td></tr></table></div><div><div>Position Fe-Cr (CANAL DROIT)</div><table><tr><th>AMPLIFICATION</th><th>POINT (d')</th><th>POINT (e')</th></tr><tr><td>FAIBLE</td><td>FERME</td><td>FERME</td></tr><tr><td></td><td>FERME</td><td>OUVERT</td></tr><tr><td></td><td>OUVERT</td><td>FERME</td></tr><tr><td>ELEVE</td><td>OUVERT</td><td>OUVERT</td></tr></table></div><div><div>Position CrO₂ (CANAL DROIT)</div><table><tr><th>AMPLIFICATION</th><th>POINT (f')</th><th>POINT (g')</th></tr><tr><td>FAIBLE</td><td>FERME</td><td>FERME</td></tr><tr><td></td><td>FERME</td><td>OUVERT</td></tr><tr><td></td><td>OUVERT</td><td>FERME</td></tr><tr><td>ELEVE</td><td>OUVERT</td><td>OUVERT</td></tr></table></div><div><div>Position Metal (CANAL DROIT)</div><table><tr><th>AMPLIFICATION</th><th>POINT (h')</th><th>POINT (i')</th></tr><tr><td>FAIBLE</td><td>FERME</td><td>FERME</td></tr><tr><td></td><td>FERME</td><td>OUVERT</td></tr><tr><td></td><td>OUVERT</td><td>FERME</td></tr><tr><td>ELEVE</td><td>OUVERT</td><td>OUVERT</td></tr></table></div></div></div></div> <div><div><div><div><div>K Courbe de réponse globale</div><div>Condition:</div><div><div>* Positions enregistrement/lecture</div><div>* Commande de niveau ...MAX.</div><div>* Commande niveau de sortie...MAX.</div><div>* Sélecteur de bande ...position Normal</div><div>...position Fe-Cr</div><div>...position CrO₂</div><div>...position Metal</div></div><div>Equipement:</div><div><div>* Voltmètre électronique</div><div>* Générateur AF</div><div>* Atténuateur</div><div>* Résistance (600Ω)</div><div>* Bande étalon vierge</div><div>...QZZCRA pour type normal</div><div>...QZZCRY pour Fe-Cr</div><div>...QZZCRX pour CrO₂</div><div>...QZZCRZ pour Metal</div></div></div></div><div><div><div><div>Nota 1:</div><div>Avant de mesurer et régler, vérifiez que la courbe de réponse en lecture est correct (pour la méthode de mesure, reportez-vous au paragraphe considéré).</div></div><div><div><div>Nota 2:</div><div>La bande d'essai QZZCRA qui sera fournie après juillet 1980 a une sensibilité d'enregistrement plus élevée dans la gamme des moyennes et des hautes fréquences.</div><div><div><div></div><div>Ce diagramme indique les valeurs standard pour le nouveau type de QZZCRA lorsque utilisé.</div></div><div><div><div></div><div>Ce diagramme indique les valeurs standard pour l'ancien type de QZZCRA lorsque utilisé.</div></div></div><div>Le nouveau type de QZZCRA est marqué comme montré sur la Fig. 20.</div></div></div><div><div><div>MESURE:</div><div><div>1. Branchez les appareils de mesure comme sur la Fig. 17.</div><div>2. Mettre la cassette d'essai (QZZCRA) en place dans le support de la cassette.</div><div>3. Placez l'appareil en position enregistrement, le sélecteur de bande sur "Normal".</div><div>4. Appliquez un signal à 1kHz du générateur AF, à travers l'atténuateur, à l'entrée LINE IN.</div><div>5. Réglez l'atténuateur pour que le niveau d'entrée soit inférieur de -20dB au niveau étalon d'enregistrement.</div><div>6. A ce moment, le niveau sur LINE OUT est de 0.07V.</div><div>7. Enregistrez les fréquences de 50Hz, 200Hz, 1kHz, 4kHz, 8kHz et 13kHz (15kHz pour bande Fe-Cr, CrO₂ Metal) à niveau constant.</div><div>8. Lisez cet enregistrement et exprimez en dB les différences entre le niveau de sortie de chaque fréquence et le niveau à 1kHz.</div><div>9. S'assurer que la valeur mesurée se trouve dans la page spécifiée dans le diagramme de réponse en fréquences généraux (Voir Fig. 19).</div><div>10. Changer la bande d'essai sur Fe-Cr (QZZCRY), CrO₂ (QZZCRX) ou Metal (QZZCRZ).</div><div>11. Positionner le sélecteur de bande sur chaque position.</div><div>12. Mesurer de la même manière de l'étape 3 à l'étape 8.</div><div>13. S'assurer que la valeur mesurée se trouve dans la plage spécifiée dans le diagramme de la réponse en fréquences totale pour les bandes Fe-Cr, CrO₂ et Metal montré dans les figures 21.</div></div></div></div></div></div></div></div></div>	AMPLIFICATION	POINT (d)	POINT (e)	FAIBLE	FERME	FERME		FERME	OUVERT		OUVERT	FERME	ELEVE	OUVERT	OUVERT	AMPLIFICATION	POINT (f)	POINT (g)	FAIBLE	FERME	FERME		FERME	OUVERT		OUVERT	FERME	ELEVE	OUVERT	OUVERT	AMPLIFICATION	POINT (h)	POINT (i)	FAIBLE	FERME	FERME		FERME	OUVERT		OUVERT	FERME	ELEVE	OUVERT	OUVERT	AMPLIFICATION	POINT (d')	POINT (e')	FAIBLE	FERME	FERME		FERME	OUVERT		OUVERT	FERME	ELEVE	OUVERT	OUVERT	AMPLIFICATION	POINT (f')	POINT (g')	FAIBLE	FERME	FERME		FERME	OUVERT		OUVERT	FERME	ELEVE	OUVERT	OUVERT	AMPLIFICATION	POINT (h')	POINT (i')	FAIBLE	FERME	FERME		FERME	OUVERT		OUVERT	FERME	ELEVE	OUVERT	OUVERT
AMPLIFICATION	POINT (d)	POINT (e)																																																																																									
FAIBLE	FERME	FERME																																																																																									
	FERME	OUVERT																																																																																									
	OUVERT	FERME																																																																																									
ELEVE	OUVERT	OUVERT																																																																																									
AMPLIFICATION	POINT (f)	POINT (g)																																																																																									
FAIBLE	FERME	FERME																																																																																									
	FERME	OUVERT																																																																																									
	OUVERT	FERME																																																																																									
ELEVE	OUVERT	OUVERT																																																																																									
AMPLIFICATION	POINT (h)	POINT (i)																																																																																									
FAIBLE	FERME	FERME																																																																																									
	FERME	OUVERT																																																																																									
	OUVERT	FERME																																																																																									
ELEVE	OUVERT	OUVERT																																																																																									
AMPLIFICATION	POINT (d')	POINT (e')																																																																																									
FAIBLE	FERME	FERME																																																																																									
	FERME	OUVERT																																																																																									
	OUVERT	FERME																																																																																									
ELEVE	OUVERT	OUVERT																																																																																									
AMPLIFICATION	POINT (f')	POINT (g')																																																																																									
FAIBLE	FERME	FERME																																																																																									
	FERME	OUVERT																																																																																									
	OUVERT	FERME																																																																																									
ELEVE	OUVERT	OUVERT																																																																																									
AMPLIFICATION	POINT (h')	POINT (i')																																																																																									
FAIBLE	FERME	FERME																																																																																									
	FERME	OUVERT																																																																																									
	OUVERT	FERME																																																																																									
ELEVE	OUVERT	OUVERT																																																																																									

SECTION	MESURES ET REGLAGES
	<p>Réglage-1 Utilisation du courant de polarisation</p> <ol style="list-style-type: none"> 1. Lorsque la courbe de réponse le gabarit entre le médium et l'aigu, comme indiqué par le trait plein de la Fig. 22, augmentez le courant de prémagnétisation en tournant les VR suivants: VR402 (canal gauche), VR401 (canal droit) 2. Lorsqu'elle est inférieure, comme indiqué par la ligne en trait interrompu, réduisez le courant de prémagnétisation en tournant les VR suivants en sens inverse. VR402 (canal gauche), VR401 (canal droit) <p>Nota: Pour la mesure du courant de prémagnétisation, reportez-vous au paragraphe correspondant en page 6.</p> <p style="text-align: center;">Réglage 2—Utilisation des bobines de correction d'enregistrement</p> <p>Lorsque la courbe de réponse est plate dans le médium et croit ou chute fortement dans l'aigu, comme indiqué par la Fig. 23, réglez en tournant les bobines suivantes de correction d'enregistrement avec les bandes normales. L203 (canal gauche), L204 (canal droit)</p>
<p>L Indicateur de niveau</p> <p>Condition:</p> <ul style="list-style-type: none"> * Position enregistrement * Commande de niveau ...MAX. * Commande de niveau de sortie...MAX. * Sélecteur de band ...position Normal <p>Equipement:</p> <ul style="list-style-type: none"> * Voltmètre électronique * Générateur AF * Atténuateur 	<ol style="list-style-type: none"> 1. Branchez les appareils comme sur la Fig. 17. 2. Comme il est montré à la Fig. 24, le branchement de la base de Q102 à la terre arrête les oscillations du multivibrateur instable comprenant Q102 et Q103. 3. Alimenter d'un 1kHz (-24dB) a la fiche "LINE IN", puis pousser le bouton d'enregistrement. 4. Régler le ATT de telle façon à ce que le niveau de sortie à la fiche "LINE OUT" devienne 0.7V (Le niveau d'entrée à cette position est nommé le niveau d'entrée standard). 5. Réglage au "-20dB". A. Réglez l'atténuateur pour que le niveau d'entrée soit inférieur de -20dB au niveau étalon d'enregistrement. B. Réglez VR101 de tel façon que le segment de -20dB s'allume dans la zone de -20dB±0.8dB. (canal droit seulement) (Voir Fig. 25). 6. Réglage au "0dB". A. Régler le ATT de telle façon à ce que le niveau de sortie à la fiche "LINE OUT" devienne 0.7V. B. Réglez VR102 de tel façon que le segment de +1dB s'allume dans la zone de 0±0.2dB du niveau d'entrée standard (Voir Fig. 26). 7. Répéter deux fois les étapes 5 à 6 ci-dessus. 8. Réglez l'ATT et vérifiez si tous les segments s'allument quand le niveau d'un signal d'entrée est augmenté de 10dB au dessus du niveau d'entrée standard (Voir Fig. 27).
<p>M Circuit Dolby</p> <p>Condition:</p> <ul style="list-style-type: none"> * Position enregistrement * Commande de niveau LINE IN...MAX. * Commande de niveau de sortie...MAX. <p>Equipement:</p> <ul style="list-style-type: none"> * Voltmètre électronique * Générateur AF * Atténuateur * Oscilloscope * Résistance (600Ω) 	<ol style="list-style-type: none"> 1. Branchez les appareils comme sur la Fig. 28. 2. Placez l'appareil en position enregistrement et le sélecteur Dolby en position OUT, puis appliquez un signal à 5kHz à l'entrée LINE IN pour obtenir -34.5dB sur TP5 (canal gauche) et TP6 (canal droit). 3. Vérifiez que la valeur en position IN du sélecteur Dolby augmente de 8 (±2.5)dB par rapport à celle obtenue en position OUT.

	Messung und Einstellung
	<p>Abgleich (zum Aufnahmeverstärker)</p> <ol style="list-style-type: none"> Den Meßaufbau zeigt Fig. 13. Gerät auf Aufnahme schalten. Sperrkreisspulen L205 (Linker Kanal) und L206 (Rechter Kanal) so abgleichen daß der Meßwert minimal wird. (S. Fig. 1). <p>Abgleich (zum Wiedergabeverstärker)</p> <ol style="list-style-type: none"> Den Meßaufbau zeigt Fig. 14. Auf Aufnahme schalten und den Monitor-Schalter auf „TAPE“ stellen. Die Filterspulen L1 (linker Kanal) und L2 (rechter Kanal) so abgleichen, daß an LINE OUT der kleinste Wert gemessen wird.
	<ol style="list-style-type: none"> Den Meßaufbau zeigt Fig. 15. Gerät auf Aufnahme schalten und Spannung am Meßpunkt 9 ablesen. Löschstrom nach folgender Formel ermitteln: $\text{Löschstrom (A)} = \frac{\text{Die Spannung über beide Enden von R403}}{1 (\Omega)}$ <p>NORMALWERT: 100 ± 20 mA (Metal position)</p> Abweichungen können durch Abgleich von VR403 korrigiert werden.
	<ol style="list-style-type: none"> Den Meßaufbau zeigt Fig. 16. Gerät auf „Aufnahme“ und Bandwahlschalter auf „Normal“ schalten. Spannung vom Röhrenvoltmeter ablesen und Vormagnetisierungsstrom nach folgender Formel berechnen: $\text{Vormagnetisierungsstrom (A)} = \frac{\text{Spannung am Röhrenvoltmeter (V)}}{10 (\Omega)}$ <p>NORMALWERT: 0.7 ± 0.3 mA (Normal position)</p> VR402 (Linker Kanal) und VR401 (Rechter Kanal) abgleichen. Den Bandsortenwähler in jede Position stellen. Überprüfen, ob der Meßwert im vorgeschriebenen Bereich liegt. <p>NORMALWERT: 0.75 ± 0.3 mA (Fe-Cr position) 1.0 ± 0.3 mA (CrO₂ position) 1.6 ± 0.3 mA (metal position)</p>
be	<ol style="list-style-type: none"> Den Meßaufbau zeigt Fig. 17. Testband (QZZCRA) in das Cassettenfach einsetzen. Gerät auf „Aufnahme“ und Bandwahlschalter auf „Normal“ schalten. Über den Abschwächer 1 kHz-Signal (−24 dB) vom NF-Generator dem IN-Eingang zuführen. Den Abschwächer so einstellen, daß der Quellen-Monitorpegel an LINE OUT 0,7 V wird. Dieses signal auf Testband aufnehmen. Die Aufnahme wiedergeben, und den Ausgangspegel an LINE OUT am Röhrenvoltmeter ablesen. <p>NORMALWERT: $0.7 V \pm 1,5$ dB (Normal position)</p> <ol style="list-style-type: none"> Falls der gemessene Wert nicht der Toleranz liegt, die folgenden VR abgleichen. VR203 (L-CH) VR204 (R-CH) Ab Punkt 3 wiederholen. Den Bandsortenwähler in jede Position stellen. Nacheinander das Fe-Cr Testband (QZZCRY), das CrO₂ Testband (QZZCRX) und das Metallpartikel-Testband (QZZCRZ) benutzen. Gerät auf Aufnahme schalten. Die Aufnahme wiedergeben, und den Ausgangspegel an LINE OUT am Röhrenvoltmeter ablesen. <p>NORMALWERT: $0.7 V \pm 1,5$ dB (Fe-Cr position) (Metal position)</p>

Gegenstand	Messung und Einstellung																																																																																										
	<p>14. Falls der meßwert nicht im vorgeschriebenen Bereich liegt, auf folgende Weise einstellen.</p> <p>15. Die Gesamtverstärkung durch Kurzschließen bzw. Unterbrechen der in Fig. 18, gezeigten Leiterbahnenstelle so einstellen, daß die Sollwerte angenähert werden.</p> <p>16. Nehmen Sie zur Einstellung der Gesamtverstärkung die untenstehenden Tabellen zur Hand.</p> <p>Fe-Cr position (LINKER KANAL)</p> <table border="1"> <tr> <th>Verstärkung</th><th>Punkt (d)</th><th>Punkt (e)</th></tr> <tr> <td>Gering</td><td>Geschlossen</td><td>Geschlossen</td></tr> <tr> <td>↕</td><td>Geschlossen</td><td>Offen</td></tr> <tr> <td></td><td>Offen</td><td>Geschlossen</td></tr> <tr> <td>Hoch</td><td>Offen</td><td>Offen</td></tr> </table> <p>Fe-Cr position (RECHTER KANAL)</p> <table border="1"> <tr> <th>Verstärkung</th><th>Punkt (d')</th><th>Punkt (e')</th></tr> <tr> <td>Gering</td><td>Geschlossen</td><td>Geschlossen</td></tr> <tr> <td>↕</td><td>Geschlossen</td><td>Offen</td></tr> <tr> <td></td><td>Offen</td><td>Geschlossen</td></tr> <tr> <td>Hoch</td><td>Offen</td><td>Offen</td></tr> </table> <p>CrO₂ position (LINKER KANAL)</p> <table border="1"> <tr> <th>Verstärkung</th><th>Punkt (f)</th><th>Punkt (g)</th></tr> <tr> <td>Gering</td><td>Geschlossen</td><td>Geschlossen</td></tr> <tr> <td>↕</td><td>Geschlossen</td><td>Offen</td></tr> <tr> <td></td><td>Offen</td><td>Geschlossen</td></tr> <tr> <td>Hoch</td><td>Offen</td><td>Offen</td></tr> </table> <p>CrO₂ position (RECHTER KANAL)</p> <table border="1"> <tr> <th>Verstärkung</th><th>Punkt (f')</th><th>Punkt (g')</th></tr> <tr> <td>Gering</td><td>Geschlossen</td><td>Geschlossen</td></tr> <tr> <td>↕</td><td>Geschlossen</td><td>Offen</td></tr> <tr> <td></td><td>Offen</td><td>Geschlossen</td></tr> <tr> <td>Hoch</td><td>Offen</td><td>Offen</td></tr> </table> <p>Metal position (LINKER KANAL)</p> <table border="1"> <tr> <th>Verstärkung</th><th>Punkt (h)</th><th>Punkt (i)</th></tr> <tr> <td>Gering</td><td>Geschlossen</td><td>Geschlossen</td></tr> <tr> <td>↕</td><td>Geschlossen</td><td>Offen</td></tr> <tr> <td></td><td>Offen</td><td>Geschlossen</td></tr> <tr> <td>Hoch</td><td>Offen</td><td>Offen</td></tr> </table> <p>Metal position (RECHTER KANAL)</p> <table border="1"> <tr> <th>Verstärkung</th><th>Punkt (h')</th><th>Punkt (i')</th></tr> <tr> <td>Gering</td><td>Geschlossen</td><td>Geschlossen</td></tr> <tr> <td>↕</td><td>Geschlossen</td><td>Offen</td></tr> <tr> <td></td><td>Offen</td><td>Geschlossen</td></tr> <tr> <td>Hoch</td><td>Offen</td><td>Offen</td></tr> </table>	Verstärkung	Punkt (d)	Punkt (e)	Gering	Geschlossen	Geschlossen	↕	Geschlossen	Offen		Offen	Geschlossen	Hoch	Offen	Offen	Verstärkung	Punkt (d')	Punkt (e')	Gering	Geschlossen	Geschlossen	↕	Geschlossen	Offen		Offen	Geschlossen	Hoch	Offen	Offen	Verstärkung	Punkt (f)	Punkt (g)	Gering	Geschlossen	Geschlossen	↕	Geschlossen	Offen		Offen	Geschlossen	Hoch	Offen	Offen	Verstärkung	Punkt (f')	Punkt (g')	Gering	Geschlossen	Geschlossen	↕	Geschlossen	Offen		Offen	Geschlossen	Hoch	Offen	Offen	Verstärkung	Punkt (h)	Punkt (i)	Gering	Geschlossen	Geschlossen	↕	Geschlossen	Offen		Offen	Geschlossen	Hoch	Offen	Offen	Verstärkung	Punkt (h')	Punkt (i')	Gering	Geschlossen	Geschlossen	↕	Geschlossen	Offen		Offen	Geschlossen	Hoch	Offen	Offen
Verstärkung	Punkt (d)	Punkt (e)																																																																																									
Gering	Geschlossen	Geschlossen																																																																																									
↕	Geschlossen	Offen																																																																																									
	Offen	Geschlossen																																																																																									
Hoch	Offen	Offen																																																																																									
Verstärkung	Punkt (d')	Punkt (e')																																																																																									
Gering	Geschlossen	Geschlossen																																																																																									
↕	Geschlossen	Offen																																																																																									
	Offen	Geschlossen																																																																																									
Hoch	Offen	Offen																																																																																									
Verstärkung	Punkt (f)	Punkt (g)																																																																																									
Gering	Geschlossen	Geschlossen																																																																																									
↕	Geschlossen	Offen																																																																																									
	Offen	Geschlossen																																																																																									
Hoch	Offen	Offen																																																																																									
Verstärkung	Punkt (f')	Punkt (g')																																																																																									
Gering	Geschlossen	Geschlossen																																																																																									
↕	Geschlossen	Offen																																																																																									
	Offen	Geschlossen																																																																																									
Hoch	Offen	Offen																																																																																									
Verstärkung	Punkt (h)	Punkt (i)																																																																																									
Gering	Geschlossen	Geschlossen																																																																																									
↕	Geschlossen	Offen																																																																																									
	Offen	Geschlossen																																																																																									
Hoch	Offen	Offen																																																																																									
Verstärkung	Punkt (h')	Punkt (i')																																																																																									
Gering	Geschlossen	Geschlossen																																																																																									
↕	Geschlossen	Offen																																																																																									
	Offen	Geschlossen																																																																																									
Hoch	Offen	Offen																																																																																									
<p>Ⓚ Gesamt-frequenzgang</p> <p>Bedingung:</p> <ul style="list-style-type: none"> * Aufnahme und Wiedergabe * Eingangsregler...MAX. * Ausgangsregler...MAX. * Bandwahlschalter ...Normal position ...Fe-Cr position ...CrO₂ position ...Metal position <p>Meßgerät:</p> <ul style="list-style-type: none"> * Röhrenvoltmeter * NF-Generator * Abschwächer * Widerstand (600Ω) * Testband (Leerband) QZZCRA für Normal QZZCRY für Fe-Cr QZZCRX für CrO₂ QZZCRZ für Metal 	<p>Anm. 1: Vor Messung und Abgleich des Gesamtfrequenzganges ist sicherzustellen, daß der Frequenzgang bei Wiedergabe korrekt ist (Vgl. entspr. Abschnitt).</p> <p>Anm. 2: Das ab Juli 1980 erhältliche Testband QZZCRA hat eine höhere Aussteuerbarkeit im mittleren und hohen Frequenzbereich.</p> <ul style="list-style-type: none"> *  Diese Werte gelten für das neue Testband QZZCRA. *  Diese Werte gelten für das alte Testband QZZCRA. <p>Das neue Testband QZZCRA ist wie in Fig. 20 gekennzeichnet.</p> <p>MESSUNG:</p> <ol style="list-style-type: none"> 1. Den Meßaufbau zeigt Fig. 17. 2. Testband (QZZCRA) in das Cassettenfach einsetzen. 3. Gerät auf "Aufnahme" und Bandwahlschalter auf "Normal" schalten. 4. 1 kHz vom NF-Generator über den Abschwächer dem NF-Eingang zuführen. 5. Den Abschwächer so einstellen, daß der Eingangspegel -20 dB des Stand-Aufnahmepegels beträgt. 6. Zu diesem Zeitpunkt beträgt der Ausgangspegel 0,07 V. 7. Bei dem gleichen Pegel sind die Frequenzen 50 Hz, 200 Hz, 1 kHz, 4 kHz, 8 kHz und 13 kHz (15 kHz für CrO₂ band oder Fe-Cr band, 16 kHz für Metal band) aufzuehmen. 8. Diese Aufnahme wiedergeben und dabei die Abweichungen der Pegel der einzelnen Frequenzen vom 1 kHz-Pegel in dB bestimmen. 9. Überprüfen, ob der Meßwert innerhalb des Bereichs liegt, der in dem Frequenzgangdiagramm angegeben ist (S. Fig. 19). 10. Nacheinander das Fe-Cr Testband (QZZCRY), das CrO₂ Testband (QZZCRX) und das Metal-Testband (QZZCRZ) benutzen. 11. Den Bandsortenwähler in jede Position stellen. 12. Bei der Messung von Schritt 3 bis 8 auf die gleiche Weise vorgehen. 13. Überzeugen Sie sich, ob der gemessene Wert in dem angegebenen Bereich liegt. (Siehe Diagramm für die Frequenzgänge von Fe-Cr, CrO₂ und Metal bande, Fig. 21). 																																																																																										

Gegenstand	Messung und Einstellung
	<p>Abgleich-1 mit Vormagnetisierungsstrom</p> <ol style="list-style-type: none"> Werden die mittleren und hohen Frequenzen gemäß der durchgezogene Linie in Fig. 22 zu stark wiedergegeben, so ist der Vormagnetisierungsstrom durch Drehen, die folgenden VR zu erhöhen. VR402 (linker Kanal), VR401 (rechter Kanal) Erfolgt ein Abfall, wie ihn die Strichlinie in Fig. 22 zeigt, so ist an diesen Reglern entgegen der Pfeilrichtung zu drehen, die folgenden VR zu erhöhen. VR402 (linker Kanal), VR401 (rechter Kanal) <p>Anm.: Für die Messung des Vormagnetisierungsstromes sei auf den Abschnitt „● Vormagnetisierung“ hingewiesen.</p> <p>Abgleich-2 mit der Entzerrerspule zur Aufnahme-Entzerrung Verläuft der Frequenzgang bei mittleren Frequenzen flach und zeigt bei höheren Frequenzen einen scharfen Anstieg oder Abfall entsprechend fig. 23 die folgenden Korrekturspulen zu erhöhen. L203 (L-CH), L204 (R-CH)</p>
● Fluorezenzmeter	<p>Bedingung: * Aufnahme * Eingangsregler...MAX. * Ausgangsregler...MAX. * Bandwahlschalter ...Normal position</p> <p>Meßgerät: * Röhrenvoltmeter * NF-Generator * Abschwächer</p> <ol style="list-style-type: none"> Den Meßaufbau zeigt Fig. 17. Wie aus Fig. 24, ersichtlich, hört der astabile, aus den Transistoren Q102 und Q103 bestehende Multivibrator zu schwingen auf, wenn der Base des Q102 mit Masse verbunden wird. Signal vor 1 kHz (−24 dB) an die Line IN-Buchse eingeben und die Aufnahmetaste drücken. ATT so abstimmen, daß der Ausgangspegel an der LINE OUT-Buchse 0,7 V wird. (Der Eingangspegel in dieser Stellung wird als Standardpegel bezeichnet). Justierung auf „−20 dB“. A. Den Abschwächer so einstellen, daß der Eingangspegel −20 dB des Stand-Aufnahmepegels beträgt. B. VR101 so abgleichen, daß im Bereich von −20 dB ± 0,8 dB das Segment −20 dB aufleuchtet (NUR LINKER KANAL) (S. Fig. 25). Justierung auf „0 dB“. A. ATT so abstimmen, daß der Ausgangspegel an der LINE OUT-Buchse, 0,7 V wird. B. VR102 so abgleichen, daß im Bereich von ± 0,2 dB um den Standardpegel das Segment + 1 dB aufleuchtet (S. Fig. 26). Die Anleitungsschritte 5 bis 6 zweimal wiederholen. Die ATT einstellen; kontrollieren, ob alle Segmente aufleuchten, wenn der Eingangspegel 10 dB höher als der Standardpegel ist (S. Fig. 27).
Ⓜ Dolby-Schaltung	<p>Bedingung: * Aufnahme * Eingangsregler...MAX. * Ausgangsregler...MAX.</p> <p>Meßgerät: * Röhrevoltmeter * NF-Generator * Abschwächer * Oszillograf * Widerstand (600Ω)</p> <ol style="list-style-type: none"> Den Meßaufbau zeigt Fig. 28. Gerät in Stellung „Aufnahme“ betreiben und Dolby-Schalter ausschalten. Dem NF-Eingang ein 5 kHz-Signal zuführen, daß an TP5 (Linker Kanal) und TP6 (Rechter Kanal) −34,5 dB erhalten werden. Prüfen, ob das Signal bei eingeschaltetem Dolby-Schalter um 8 (± 2,5) dB größer ist als bei ausgeschaltetem Dolby-Schalter.





Parts Change Notice

(D)...For all European areas except United Kingdom.
(B)...For United Kingdom.
(N)...For Asia, Latin America, Middle East and Africa areas.

Model No.

RS-M260

Please revise the original parts list in the Service Manual to conform to the change(s) shown herein. If new part numbers are shown, be sure to use them when ordering parts.

Reason for Change		*The circled item indicates the reason. If no marking, see the Notes in the bottom column.			
1. Improve performance					
2. Change of material or dimension					
3. To meet approved specification					
4. Standardization					
5. Addition					
6. Deletion					
7. Correction					
8. Other					
Interchangeability Code		**The circled item indicates the interchangeability. If no marking, see the Notes in the bottom column.			
Parts		Set Production			
A	Original		Early	Original or new parts may be used in early or late production set.	
	New		Late	Use original parts until exhausted, then stock new parts.	
B	Original		Early	Original parts may be used in early production sets only. New parts may be used in early or late production sets. Use original parts where possible, then stock new parts.	
	New		Late		
C	Original		Early	New parts only may be used in early or late production sets.	
	New		Late	Stock new parts.	
D	Original		Early	Original parts may be used in early production sets only. New parts may be used in late production sets only. Stock both original and new parts.	
	New		Late		
E Other					
Part Number					
Model No.	Ref. No.	Original Part No.	New Part No.	Notes (* - **)	Part Name & Descriptions
RS-M260	G3(N)	QGCM0037 (Black)	QGCM0036 (Silver)	3-D	Bottom Cover
"	G5(D)	QYT0586K (Black)	QTY0586 (Silver)	"	Volume Knob-A Assembly
"	G6(D)	QTY0587K (Black)	QTY0587 (Silver)	"	Volume Knob-B Assembly
"	G7(D)	QG01692K (Black)	QG01692 (Silver)	"	Push Button (Power ON/OFF)
"	G8(D)	QG01694K (Black)	QG01694 (Silver)	"	Push Button (Monitor/Dolby NR/ Input Select)
"	G9(D)	QGT1515K (Black)	QGT1515 (Silver)	"	Counter Knob (Tape Select/ Output Level)
"	G40(N)	XWC3B	—————	6-D	Washer(3φ)
"	P4(D/B)	XZB40X60A02	XZB50X65A02	3-D	Poly Bag

File this Parts Change Notice with your copy of the Service Manual.

Original Service Manual is Model No. RS-M260(D/B) Order No. ARD8008083C.

(N) Order No. ARD8012131A01.

Technics
National / Panasonic
Matsushita Electric Trading Co., Ltd.

P.O. Box 288, Central Osaka Japan

Printed in Japan